

# FM VOYAGER™

## FM Transmitter

Model #20800

Thank you for purchasing FM Voyager - the Premium Hi-Fi FM Stereo Transmitter! FM Voyager allows you to play your MP3, CD, DVD, or other portable music player through your vehicle's FM Stereo.

IF YOU HAVE ANY TROUBLE WITH THE INSTALLATION OR USE OF THIS PRODUCT, PLEASE DO NOT RETURN TO THE STORE. Free Technical Support is available by calling 1-800-337-4468.

### CAUTION




Keep away from water, liquids, or moisture.



Do not leave the FM Voyager in direct sunlight for extended periods of time. Excessive heat may cause damage, which is not covered under warranty.

Unplug the FM Voyager when not in use.

### Package Contents:




1 Fm Voyager Stereo FM Transmitter



1 Retractable cord with 1/8" stereo headphone connectors at each end

### Getting Started:

- 1) Plug either end of the retractable cord into the jack on the FM Voyager
- 2) Plug the other end of the retractable cord into the headphone jack of your music player.



Note: Adapters are available at various electronic retailers which allow you to connect FM Voyager to other types of audio output jacks. If the retractable cable is lost or damaged, a 1/8" stereo cable will also work. Replacement retractable cables are available through [www.designtech-intl.com](http://www.designtech-intl.com).


- 3) Turn ON your music player and adjust its volume to the mid point (half-way).
- 4) Plug the FM Voyager into your vehicle's cigarette lighter (12V power) socket. The digital channel display will illuminate showing the last used channel. The colored ring around the body of the FM Voyager will also illuminate, indicating the unit is transmitting.
- 5) The FM Voyager has 12 channels available for transmission. Select a clear (station-free) channel in your area from the chart below. Once you have selected a channel, press the small button on the side of the FM Voyager repeatedly to change the channel until the display reaches the desired channel number. Note: The FM Voyager will remember the last channel used.

CH 01 = 88.1	CH 06 = 106.7
CH 02 = 88.3	CH 07 = 106.9
CH 03 = 88.5	CH 08 = 107.1
CH 04 = 88.7	CH 09 = 107.3
CH 05 = 88.9	CH 10 = 107.5
	CH 11 = 107.7
	CH 12 = 107.9

Channel  
Button



- 6) Tune your vehicle's FM radio to the frequency on which you set the FM Voyager to transmit (in step 5).



- 7) You should now be able to hear the music from your portable music player through the vehicle's radio. You may want to save this station as one of the preset stations on your car stereo.

**Helpful Tips on Using FM Voyager:**

- 1) FM Voyager has a typical effective range of 5 to 10 feet, but this range will depend greatly on the quality of the receiver and the environment in which the product is being used. FM Voyager uses the 1/8" retractable cord as an antenna. For maximum range, make sure the retractable cord is fully extended.
- 2) If the sound is not clear, you may need to adjust the volume of your music source. Too low of a volume may result in excessive background "hiss", while too high of a volume may result in audible distortion. Keep in mind that adjusting the volume of your music source will also affect the received volume. Also make sure that no radio station is interfering on this channel.
- 3) Hearing a slight "hiss" or "static" on your FM Radio is normal, especially during quiet intermissions.
- 4) You may need to select a different channel to reduce/eliminate interference from local stations as you drive from area to area.
- 5) If the FM Voyager does not turn on (the lights do not come on) when plugged in, check the fuse box in your vehicle to make sure the fuse to the cigarette lighter adapter is intact. If the fuse in your vehicle is okay, unscrew the cap on the FM Transmitter and check the fuse inside. If necessary, replace the fuse with an identical 0.5 Amp fuse.

Warning: Changes or modifications to this unit not expressly approved by DesignTech International, Inc. could void the user's authority to operate this equipment.

FCC ID: ELGFMTX1

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**ONE YEAR LIMITED WARRANTY**

DesignTech International, Inc. warrants to the original consumer/purchaser that this product shall be free of defects in material and workmanship under normal use and circumstances for a period of **one** (1) year from the date of original purchase for use. When the original consumer/purchaser returns the product, pre-paid to DesignTech International Inc., 7955 Cameron Brown Court, Springfield, Virginia 22153-2809, USA within the warranty period, and if the product is defective, DesignTech International, Inc. will at its option repair or replace such.

This warranty shall constitute the sole liability of DesignTech International, Inc. concerning the product. DesignTech International, Inc. expressly disclaims all other warranties INCLUDING, WITHOUT LIMITATION, THE WARRANTIES OF MERCHANT ABILITY AND FITNESS FOR A PARTICULAR PURPOSE. NO PERSON, FIRM, OR CORPORATION IS AUTHORIZED TO ASSUME FOR DESIGNTech INTERNATIONAL, INC. ANY OTHER LIABILITY IN CONNECTION WITH THE SALE AND USE OF THE PRODUCT. DesignTech International, Inc. and agents and distributors will bear no liability whatsoever for incidental or consequential damages or charges of any kind.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above disclaimer regarding incidental or consequential damages may not apply to you.

This warranty is void if the product has been damaged or tampered with or if the product or any such parts have been opened. In all cases of damage during shipment, a claim must be filed with the shipping carrier and not with DesignTech International, Inc.

This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

**OUT OF WARRANTY REPAIRS**

If the warranty period has expired or if you are not the original owner of the product, DesignTech International, Inc. will at its option either (1) replace this product with a functionally similar (but not necessarily identical) refurbished product and return it to the original consumer/purchaser after payment of replacement charges has been received or (2) repair the original product and return it to the original consumer/purchaser after payment of repair charges has been received.