

## CW Watch R1 G

User Guide







Step 3: Insert the longer band into the second loop




Support full-screen touch (swipe, tap,


touch and hold)






and adjust brightness and volume swiftly.









Install New Watch Faces

preferred watch face.


In the Fitbeing app, navigate to the

Face Gallery page to pick up your


Make sure the USB charging plug is at the same side as the Ensure to use a standard USB power source with an output of 5V=1A or above. Prior to charging, ensure to clean the charging contacts of the watch to eliminate any lingering sweat or moisture.

To charge the watch, connect the charging cable to a USB power source. Attach the other end


to the charging contact on the back of the watch. The watch will display a charging icon while



1. Insert the metal pin at position "A" in the hole. 2. Push and hold the spring bar. 3. Press the band into the body and release the spring 4. Pull the watch band to confirm the firm installation. Spring bar -—



burning sensation, take off the watch and rest your wrist. To maintain hygiene, regularly clean your watch and wrist, two finger-widths from your wrist bone. particularly after workouts and sweating. Avoid using hand soap, 2. For comfort, adjust the band to allow a shower gel, dishwashing liquid, or cleaning wipes as they can cause



## · Do not replace the built-in battery yourself as it may pose a safety risk. · Avoid forcibly opening the watch case, as it may cause short circuits and leakage or explosion.

**Precautions** 

**Help and Guide** 

· Keep the watch away from environments exceeding 60°C to prevent battery · While the product complies with 3ATM waterproof standards, it is not recommended for activities such as bathing, diving, or water skiing that involve high temperatures, steam, or rapid water flow. Note that the waterproof performance may be compromised if the product structure is damaged.

· Be aware that firmware upgrades can lead to interface and usage changes. For detailed information, please refer to the product's upgrade instructions.

more of the following measures: Reorient or relocate the receiving antenna. Frequently Asked Questions

If you encounter any problems while using the product, you can access the "Profile  $\rightarrow$  Help & Support" section in the Fitbeing app for assistance. Scan the QR code on the right to access or visit

Scan the QR code on the right to access it, or visit help.fitbeing.com to browse.




exempt RSS(s). Operation is subject to the following two conditions: This device may not cause ....

2. This device must accept any interference, including ....
cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux

CNR d'Innovation, Sciences et Développement d'applicables aux appareils radio
autorisée aux d'autorisée aux d 2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le






Note: If the watch can't power on, it may be because the battery

approximately 10 minutes and wait for it to power on


automatically.





1. Press the digital crown to wake up the screen.


the watch face screen.


2. Press the digital crown to enter the app center from
















Charge the Watch













Product Name	CW Watch R1 G
Display	1.43" HD AMOLED
Resolution	466 × 466
Battery Capacity	370 mAh
Wireless Connection	Bluetooth 5.3
Water resistance garde	3ATM
Satellite positioning	Support GPS
Geomagnetic sensor	Support compass
Air pressure sensor	Supports elevation
Body Dimension	46.8mm × 46.8mm × 10.8mm
Working Temperature	0°C ~ 50°C
Compatible Operating Systems	iOS 13.0 and above, Android 9.0 and above

FCC Requirement

Any changes or modifications not expressly approved by the party This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. this device may not cause harmful interference, and 2. this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits a residential installation. This equipment generates, uses, and can radiate

radio frequency energy, and if not installed and used in accordance with the However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

 Increase the separation between the equipment and receiver. Consult the dealer or an experienced radio/TV technician for help.