

# User's Manual

Bluetooth speaker  
User's Manual  
T2, BDY-9087, EXTREME



KINGTA TECHNOLOGY CO.,LTD

T2

## Introduction:

you can use this item with tablet,notebook and many types of  
Troubleshooting  
Smart phone to stream music,and enjoy hands free calling.In order to get  
the best results when using the device,please read this manual first before  
using.


## Feartures

- Volume and song control directly on speaker unit
- Stunning sound clarity
- Ultra portable design
- Great for parties, indoor and outdoor
- Allow you to make and answer phone calls
- TF card can use

## Specifications

Loudspeaker: 4Ω 3W\*2  
Built-in Power:3.7V/2000mA  
Dimensions: L166\*W62\*H68.2MM  
SNR: ≥80DB  
Wireless Working Frequency: 2.402-2.480GHZ  
Wireless Transmission Distance: up to 32 ft  
Charging Time: 3-4 hours  
Weight: 350.3g  
Speaker Dimension:40mm  
Charging: DC5V±0.5/500MA

## Package Contents



1. Bluetooth  
Speaker

USB Charging cable



Audio Cable

2.





3. Bike Buddy

1. Keep this product and its charging cable away from excessive heat.
2. Do not operate this device with a damaged cable or after it has malfunctioned or has been damaged in any manner.
3. Do not disassemble your device.

## Charging Your Speaker

1. Connect one end of the included USB Charging Cable to the Charging Port on your speaker. Then plug the other end of the USB Charging Cable into a suitable USB port on your computer to recharge your speaker's internal rechargeable battery.  
NOTE: The internal battery of your speaker takes approximately four hours to charge when completely drained.
2. When charging, a red LED light will illuminate to indicate that the unit is charging. The red light will turn off when your unit is fully charged.

## A Quick Look at Your Device



1. Previous : Press to access the last track in playlist.Press and hold to lower the volume
2. Phone : Press this button to activate the the speaker phone function. When music is playing, press to play or pause a track.
3. Next : press to access the next track in a a playlist.Long press and hold to increase the volume.

## 4. Charging Port

You can plug one end of the included USB Charging Cable into this jack, while plugging the other end into a USB port on your computer in order to charge your speaker's built in lithium battery.

## 5. ON/OFF Switch

Press and hold the "to power on  
Press and hold the "again to power off

## Understanding the LED Status Lights

### When Charging Your Speaker

Solid red LED = Charging  
No red LED = Charge Complete

### When Pairing Your Speaker to a Bluetooth Audio Source

Rapid blinking blue LED: Bluetooth not connected. (Ready to pair.)  
Solid blue LED: Bluetooth connected.!

## Pairing Bluetooth Devices to Your Speaker

In order to pair your Bluetooth audio device to your Bluetooth Speaker for the first time, follow the steps below:

- 1). Make sure your Bluetooth audio source is held within three meters of your speaker.
- 2). Press and hold the switch on your speaker to power on  
The LED light will blink blue to indicate that you have entered pairing status.
- 3). Go to the Bluetooth Manager of your Bluetooth audio source. Please refer to the User's Manual of your Bluetooth audio source for more information.
- 4). Search Bluetooth devices and select "T2".
- 5). Once paired, the blue LED light will be solid and you can use your speaker to listen to audio from you Bluetooth sound source.

## Using the Hands-Free Function

When an iPhone or other smartphone is connected to your speaker follow the steps below to take calls hands-free.

1. Press "to pick up the call.
2. Press and hold "for 2 sec to reject the call.
3. During a call: Press "again to hang up the call.

## Troubleshooting

| Problem                                             | Solution                                                                                                                                                                                                                                 |
|-----------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The speaker doesn't connect to device               | Speaker needs to be connected/paired again to device                                                                                                                                                                                     |
| A tone is heard every few seconds                   | Speaker needs to be charged                                                                                                                                                                                                              |
| Bluetooth connection distance cannot reach to 32ft. | Avoid operating the Bluetooth speaker in areas of strong electromagnetic interference,such as near induction cookers,large power fans,motors etc.<br>Move the speaker closer to Bluetooth device.Fully charge the speaker and try again. |
| The speaker will not power on                       | Speaker needs to be charged                                                                                                                                                                                                              |
| The speaker doesn't control track(s)/volume         | Speaker needs to be in Bluetooth mode for full control                                                                                                                                                                                   |
| The speaker sound is distorted at high volume       | The devices' volume needs to be lowered                                                                                                                                                                                                  |

## Important Safety Precautions

When using your Bluetooth Mobile Speaker, basic safety precautions should always be followed, including the following:

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.