Model:BM01

comfyer^obaby Baby monitor user manual



ACTIVATE WARRANTY



2- YEAR ScanQR code toactivate extended warranty


CONTENTS

1. WARNINGAND SAFETY INSTRUCTIONS	1
2. PRODUCTOVERVIEW	
3.POWERINGON YOUR PRODUCT	
4.USINGTHEBABY MONITOR	5
5. TROUBLESHOOTING	
6.TECHNICALDATA	11
7.FCCREQUIREMENT	
8.MAINTENCE	
9.WARRANTY & SUPPORT	

1.WARNING AND SAFETYINSTRUCTIONS

Follow thesesafety precautions to prevent fireinjury or damage to the product.Read and keep instructions:it is very important that you read allthe safety and operating.

Warnings:



STRANGULATION HAZARD:Children can become entangled in cords.Make sure the baby unit,parent unit and mains adapter cables are kept out of reach of you baby and other young children at alltimes,at least 6feet away.

CHOKING HAZARD:This product containssmall parts wichmay cause choking.Exercise care when unpacking and assembling the product and keep the small parts away from children.

RISK OF SUFFOCATION:Keep all packaging materials and protective foils out of reach of children.

DANGERFROMPOWER CORDS: To avoid possible dangerfrom power cords the cords should be secured and never be hung onor near the crib,Never place the baby unit or parent unit inside your baby'crib,bedor playpen. DO NOT HANDLE ROUGHLY, DROP ORTHROW: Baby monitor is a high-quality electronic devicewhich must be handled with care WATER AND MOISTURE: The product should not be exposed to rain, moisture, or splashing. Never use or place the product in or near moisture or water.

THIS PRODUCT CANNOT REPLACE RESPONSIBLE ADULTSU-PERVISION: Your video monitor is designed to be an aid and should not be used as a substitute for responsible and proper adult supervision of a child

VENTILATION: This product should not be used on a bed,sofa, rug or similar surface that may block the ventilation or speaker openings,or be placedin an enclosed area,such an a book case or drawer that may impede air flow.Never cover the product with clothes,towels.Never cover the product with clothes,towels, blankets or any other item.

THIS PRODUCTIS NOTATOY: it should be kept out of children's reach.

KEEPAWAY FROM SOURCES OF HEAT: This unitshould not be exposed to direct heat sources such as a candle, stove, radiator, heat register or other appliance that emit heat. the unit should not be left in directsunlight

BATTERY:Before you use the product, we recommend you fully charge the battery of the parent unit, so that it continues to work if you disconnect it from the power supply to carry it to another location.

INSTALLATION LOCATION: The installation location plays an important role in ensuring proper operation, Therefore, maintain a distance of at least5 feet from otherelectronic equipment, such

as microwave ovens orWi-fi routers,otherwisethey could cause interference.If this occurs,move the baby and parent units to another location. RANGE: Range of all baby monitor is always measured in an open

RANGE: Range of all baby monitor is always measured in an open space.Theactual range may be shortened due to environmental obstacles (such as concrete walls).

DAMAGE REQUIRING SERVICE: This product should be serviced by qualified personnel only

DO'NOT TRY TO OPEN AND REPAIR THE PRODUCT: If you have any problems with the product, please contact the authorized distributor, In case of unusual noises orsmells originating from the device, immediately disconnect the product from the power outlet and contact authorized. If the product becomes dirty, use a lightly damp soft cloth to wipe surfaces, taking care to notallow water into any openings.

IMPORTANT: This baby monitor is designed onlyfor hearing the baby's voice and seeing the images of the baby, This product is not

a medical device and should notbe used as a substitute for responsible adult supervision.it is important that you regularly check on your baby personally.

1.2 Safty Instructions for AC PowerAdapter

The adapter should not be exposed to direct heat sources such as as candle, stove, radiator, heat register or other appliance that emit heat.

During continual use, the power adapters may become warm to

the touch. This is normal and should not be a cause of concern. Examine intactness of the power cord and its plug. The adapter

must be handled with care:Do not handle roughly,drop or throw. When removing the power adapter from the wall outlet,hold and pull from the receptacle.Do not pull on the cable itself or bend the cable as that will put additional stress on thecable and could lead to damages

Do not touch the power adapter with wet hands or allow liquids to spill on it.Makesure the mains adapter cables arekept out of reach of your baby and other young children at all times.

To avoid possible danger from power cords the cords should be secured and never be hung on or near the crib.

Do not replace the plugsor cable on yourpower adapter, This product should only be used with the AC power adapter supplied by the manufacturer, as included in this package.

Never cut, damage or bend the power cord.

Do not put any objects on top of the power cord, which could cause overheating, damage

combustion and electrocution

Do not leave the power adapter connected to the wall outlet when it is not plugged into the baby or parent unit.

Warning

Do not replace the power cordwith non-original substitutes,

improper connection may cause electrocution,Do not place the AC adaptor cable in a high wear and tear location.Never use a frayed or compromised cord.intended for indoor use only.

1.3 Safty Instructions for Li-ion battery(Non removable pre-installed battery)

Do not attempt torepair or adjust any of the electricalor mechanicalfunctions of the unit.Do not dismantle,cut,open, crush,bend,puncture,or shred cells or batteries if a battery leaks, do not let the battery liquid touch skin or eyes.If this happens, immediately flush the affected areas with water,and seek medical assistance.

The battery should not beexposed to direct sunlight or heat sources such as a candle,stove,radiator,heat,register or other appliance that emit heat.Do not modify,manufacturer,attempt to insert foreign objectsinto the battery,or immerse or expose it to water or other liquids.Batteries may explode if damaged. Use onlythe battery pack supplied with the product or the same type,sold by the manufacturer or its authorized distributors. Improperuse oruse of unapproved batteries may present arisk of fire,explosion,or other hazards,and may invalidate the warranty.if you believe the battery is damaged,remove product from the charge and stop using the product. Never use a damaged battery.

1.4 Information on disposal of product

Always dispose of your product(with the non removable preinstalled battery)at the end of their life inan environmentally responsible way and in accordance with your local waste disposal requirements.All cardboard and paper packaging materials should be recycled in accordance with your local council waste regulations

PRODUCT OVERVIEW

2.1 Parent unitoverview:



OPower key Long press to turn on/off the monitor;short press to screen on/off

2 Volume up

Press Volume+to increase the volume.

Brightness down Press the Bright-to decrease the brightness.

0Volume down

Press volume-todecrease the volume.

OMenu

Short press the menu key the

menuwill pop up and press again to Exit.

O Power&Charging LED

*the LED shows red when charging under the display is turn off state. *the LED shows orange when

charging under the turn on

state.

*the LED shows green when the **battery is fully** charged.

(1) Microphone

When talkto the baby,collect the voices of the parents.

θPan/Tilt

Pressthe keyosto enter into the Pan/Tilt mode 9 Brightness up Press theBright+to increase the brightness 00K key

Press theOKkeyto confirm **①Talk to baby**

To talk, press and hold the talk key on the front of the monitor.

2.2 Baby unit overview



0 Light sensor 2 Infrared LEDs 3 CMOSIens

0 Microphone6 Antenna0 DCjack



2DCjack

BSpeaker

Stand

BBatterydoor

Chargethe monitor by

connecting the Power Adapter

Hearthe sound from the baby.

to the monitor and a socket

Monitor placement stand.

⑦ SpeakerTemperature sensorO Pairing key

2.3 Icon Overview

月	-Lullaby	Time Format
_	VOX	章 Brightness
+	-Zoom	- Timer
9	Camera	LER Alert Volume
_	Setting	506k FrequencySetting
C/F	Temp C/F	o Temp

2.4 Product list



Baby Unit

(Camera)

<u>_1</u>

8

Parent Unit



Silicone bracket (*This accessory is not included in the single lens kit)



Screw Set

User Manual

AC Power Adapter

3.POWERING ONYOUR PRODUCT

Step1: Charge the baby unit.



Step3: Set the parent unit to prepare for connecting.



NOTE:I fthe baby unit and parent unit has been connected,the steps 3 and 4 are unnecessary.

Step2: PressOfor two seconds to Power on the parent unit



Step4: Press the PAIR button for

two seconds until it has been paired(the★symbol appears before鲁).



4.USING THEBABY MONITOR

Music Seting

- 2.Select the lullaby you want to play and press6

3. Pressthe NAVIGATION key to select he duration and music

volume. 4.In order to stop the lullaby playback,select]

5.Press menu button \equiv to exit the menu.

NOTE: Thelullabydefault setting isoft.



yOX Setting

1.Press menu button \equiv to access menu.choose 8 and press 3 2. Press the Up keyao r DOWN keyalito select the VOXlevel. 3.Press @to confirm

4.Press menu buttonΞ to exit the menu.

NOTE: To resume the video and audio signal manually on yourparent unit when VOX function is on,briefly press any key on your parent unit.



Zoom in/outsetting

1.Press menu button — to access menu.choose and press③. 2.Pressthe UP keyillor DOWN keya to select the magnification. 3.Pressto confirm. 4.Press menu button — to exit the menu.



Split screen

4. Press menu button \equiv to exit the menu.

NOTE: This function is only available whentwo or more cameras are paired.



Add camera

1.Press menu button to access menu choose _ and press 2.Press the Up key ol or DOWN key oito select the camera to be paired. 3.Press to start the pair ing , whi is the screen shows pairing then press PAIR button on the back of the camera.

4. Press menu button \equiv to exit the menu

NOTE:Before youbegin pairing,make sure to have thebabyand parent unit side by side and turned on.



Delete camera

1.Press menu button Eto access menu.chooseO and press 2.Press the Up keya(llor DOWN keyo(i to select the camera to be canceled 3.Press@to confirm.

4. Pressmenu button \equiv to exit the menu.



Temperature unit setting

- 1.Pressmenu button = to access menu.Choose o and press
- 2.Selecto?°C/F and press@
- 3.Press the UP key Ilor DOWN keya(Ito select °C or °F
- 4 Press to confirm

5. Press menu button \equiv to exit the menu



Temperature alert setting

- 1.Press menu button Eto access menu.Choose oand press
- 2.Selectd glland press³ 3.Press the UP key mor DOWN key lito set the maximum and minimum alarm temperatures.
- 4.Pressto)confirm.

5 Press menu button \equiv to exit themenu



Time setting

- 1.Press menu button = to access menu.Choose and press
- 2.Selectia and press
- 3.Pressthe UP key lor DOWN key lito select 12H or24H 4.Press to confirm.

5 Pressmenu button \equiv to exit the menu



Language setting

1. Press menu Lutton = to acc # ss menu. Choose d and press 2. Se lect_angli age and press 3 3. Press the UP key lor DOWN keyato select the language.

4. Pressto confirm. 5. Press menu button \equiv to exit the menu.



Timer setting

1.Press menu button Ξ to access menu.Choose B and press 2.SelectO and press 3

3.Press the UP key mor DOWN keyalito select the desired alert time. 4.Press@to confirm. 5.Press menu button = to exit the menu.



Alert volume setting

Pressmenu button = to accessmenu. Choose a and press@
 Selectg ALERTand press®
 Press the UP keyoil or DOWN key lito select the desired alertvolume.
 Press to confirm.

5.Press menu button Ξto exit the menu.



Frequency setting

 $1.8 \text{ress}_{\text{max}}$ m $_{\text{max}}$ how n = to access menu. Choose o and Qpress 2.5 e is to 0.660 Hz and press 3.Pressthe UP keymor DOWN keyoljto select 50Hzor60Hz 4.Press to confirm. 5. Press menu button \equiv to exit hemenu.



Nightvision setting

1. Press menubutton — to access menu. Choose and press 2. Select≑ NghtVson and press 3. Press the UPkey ∭or DOWNkeyo(Ito select the state of nightvision 4 Pressto confirm

5.Press menu button = to exit the menu



Camera angle setting

1.Press menu button = to access menu.Choose a and press

2.Select (9)o/aoand press

 $3.P_{\mbox{ress}}$ th $\hfill UP k e yaillior DOWN key alito select the angle at which the camera eisplace d$

4. Pressto confirm 5. Press menu button Ξ to exit the menu.



Key Description



Volume/Brightness adjustments

Press om oraji to increase/decrease the sound of the parent unit. Press*or 案 to increase/decrease the brightness of the parent unit

__9__

Switching between the paired baby unit Briefly press the switch button@onyour

parent unit





Scan mode

Press and hold the button@to activatethe automatic scan mode Press the button@to deactivate thescan mode

Talk to baby

Press and hold the buttonytotalk to your baby Release the button when you are finished talking



5 TROUBLE SHOOTING

	Trouble shooting
No reception on the Parent Unit	 The power adapters may not be properly Connected Ensure that the Baby and Parent Units are ON Make sure the Baby Unit and Parent Unit are not far away from eachother Baby Unit and Parent Unit may not be properly paired. Follow PAIRING instructions
Interference or poo reception	 Move the Baby Unit closer to Parent Unit. The Baby or Parent Unit may be too close to metal objects Other electronic devices may be intering with the signal The battery power may be too low
Image frozen on the Parent Unit	 Restart the Baby Unit(pull out the poweradapter from the wall outlet, wait for approx.5 seconds and plug it back in). Reset the Parent unit by opening the battery compartment and disconnecting the battery wait for 30 seconds and then reconnect the battery
A high pitched ear piercing noise is heard from the units (feedback,static)	The Baby Unit and Parent Unit maybe too close to each other, move them further apart The volume on the Parent Unit may be set too high
Cannot hear the baby sounds on the Parent Unit	• Volume setting on the Parent Unit may be too low.increase the volume.

Background noises	 In a quiet environment surrounding the Parent Unit, decrease the volume on your Parent Unit to level 3 and below In aloud environment surrounding the Parent Unit increase thevalume on your Parent Unit to
	Unit, increase thevolume on your Parent Unit to the maximum level

If above tips are not help;maybe the system crashed, please disconnect the battery and the power adapter with your unit;then plugin it again and turn your unit.

TECHNICAL DATA SHEET

	Technical data sheet
Mode1	BM01
Frequency	2. 4GHz FHSS
Type of modulation	GFSK
Transmission	Up to 960 feet/300 meters(Open space, no obstruction)
Input voltage	5V, 1/1. 2A
Power adapter	Input:100-240VAC 50/60Hz,200mA Max
LCD screen	7"HD TFT LCD
Rechargeable battery	3.7V, 4000mAh
Transmition Power	18dB
Imagesensor type	1/2.9"Color CMOS,1920*1080pixels
IR LED Type	940nm
Operating environment	Indoor use only;Temperature:32-104° F/0-40°C Humidity:5%-90%rh(relative humidity)

7.FCC Requirement

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority ooperate this equipment.

This equipment complies with FCC radiation exposure limits set for th for an uncontrolled

environment. This equipment should be installed and operated

with minimum distance 20cm between the radia for a nd your body.

ISED Statement

-English: This device complies with Industry Canada license -exempt RSS standard(s). Operation is subject to the following two conditions:(1) This devicemay not cause interference, and(2) This device must accept any interference

including interference thatmaycause undesired operation of the device

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B)

-French:Le présentappareilestconforme aux CNR d'ndustrie Canada applicables aux appareils radio exempts de licence. Lexploitationestautorisee aux deux conditions suivantes:(1)I appareilne doit pasproduire de brouillage,et(2)Iutilisateurde appareildoit accepter tout brouillageradioélectriquesubi,memesi le brouillageest susceptible d'encompromettre lefonctionnement Iappareil numérique duciem conforme canadien peut-3(b)/nmb -3(b). This devicemeets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF

exposure.users can obtain Canadian

information on RF exposure and compliance.

cet appareil est conforme à lexemption des limites d'évaluation

courante dans lasection 2.5 du cnr-102 et conformité avec rss 102 delexposition aux rf,les

utilisateurs peuventobtenir des données canadiennes sur lexpositionaux champs rf et la conformité.

This equipment complies with Canada radiation exposurelimits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non controlé.

The device for operation in the band 5150-5250 MHz isonly for indooruse to reduce the potentialfor harmful interference to co-channelmobile satellite systems

Lappareil destiné à fonctionnerdanslabande 5150-5250 MHz est uniquement

destiné à une utilisation en intérieur afinderéduire le potentiel d'interférences nuisibles aux systèmes mobiles par satellite

cocanaux

This equipmentshould be installed and operated with minimum distance 20cm between the radiator &your body.

Cet équipement doit etre installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

3.MAINTENANCE

All ofthe following maintenance procedures should only be performed when baby and parent units are unpluggedand off. Clean the surfaces of the baby and parent units with a soft, fluff-free cloth.Never use cleaning agents or solvents.If the units become dirty,use a lightly damp clothto wipe surfaces,taking care not to allow water into any openings.

WARRANTY

9.1 Warranty

The comfyer BM01 Video Baby Monitor comes with a full 12 months limited warranty. If you register your product onour official site (www.comfyer.net/register)orjust scam the QR Code inthe user manual homepage, you can extend thewarranty to 24 months.

9.2 Support

If you have any questions regarding your product, please do not hesitate to dropus an email at**support@comfyer.net**.Queries are typically answered within 12-24 hours.

9.3 Your opinion matters

comfyeris firmly committed to always improving our products, services, and user experience. If you have any thoughts on how we can do even better, we welcomeyour constructive feedback and suggestions. Connect with us today at support@comfyer.net.

comfyer⁸baby

www.comfyer.net Made in Chin



FCC Statement

This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including

nterference that may cause undesired operation.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

(1)Reorient or relocate the receiving antenna.

(2)Increase the separation between the equipment and receiver.

(3)Connect the equipment to an outlet on a circuit different from the receivers.

(4)Consult the dealer or an experienced radio/TV technician for help.

Radio Frequency Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in fixed/mobile exposure condition. The min separation distance is 20cm.

ISED Statement

- English: This device complies with Industry Canada license -

exempt RSS standard(s). Operation is subject to the following

two conditions: (1) This device may not cause

interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES -3 (B)/NMB -3(B).

- French: Le présentappareilestconforme aux CNR d'Industrie

- Canada applicables aux appareils radio exempts de licence. L'
- exploitationestautorisée aux deux conditions suivantes: (1) l'
- appareilne doit pas produire de brouillage, et (2) l'utilisateur de l'appareildoit accepter tout brouillageradi oélectriquesubi, mêmesi le brouillageest susceptible d'encompromettre le
- fonctionnement. l'appareil numérique du ciem conforme canadien
- peut 3 (b) / nmb 3 (b).
- This device meets the exemption from the routine evaluation
- limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian
- information on RF exposure and compliance.
- cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr 102 et conformité avec rss 102 de l'exposition aux rf, lesutilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.
- This equipment complies with Canada radiation exposure limits
- set forth for an uncontrolled environment.
- Cet équipement est conforme aux limites d'exposition aux
- rayonnements du Canada établies pour un environnement non contrôlé
- This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.
- Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.