Material: 100gsm Wood free Paper

Jun. 20, 2018

Back Cover



Front Cover

FCC Information

FCC ID: EMOIHV110

Printed in China

This device complies with Industry Canada's licence-exempt RSSs.

Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read and follow all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions

Water and Moisture - The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.

Cleaning - The unit should be cleaned only with dry cloth. Do not use solvents, etc

Heat - The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.

Only use attachments/accessories specified by the manufacturer.

Damage Requiring Service - The unit should be serviced by qualified service personnel when:

- A. the power supply cable or plug has been damaged.
- B. objects have fallen into or liquid has been spilled into the enclosure. C. the unit has been exposed to rain.

- D. the unit has been dropped or the enclosure damaged.

 E. the unit exhibits a marked change in performance or does not operate normally.

Attention should be drawn to the environmental aspects of battery disposal



For warranty information: visit https://www.ihome.com/support

iHv115-062018-A

iHome



Quick Start Guide

Bluetooth Wireless Sport Earbuds

Model: iHv115

What's Included:

- Bluetooth Wireless Sport Earbuds with control dongle
- Silicon Ear Cushions
- USB Charging Cable

CHARGE BEFORE USE



Questions? Visit www.ihome.com/support or call 1-800-288-2792 Toll Free



iHv115 - QSG (English Only)

GETTING STARTED

Charging your earbuds

Earbuds must be charged before use.





• Earbuds should provide about 4 hours of audio when fully charged.

BLUETOOTH

Pairing establishes a unique communication connection between your Bluetooth device and the earbuds. Once paired, you will be able to stream audio wirelessly to your Bluetooth Wireless Sport Earbuds.



- 2-3s 1 The FIRST TIME EARBUDS ARE POWERED ON they enter auto-pairing mode. The LED indicator on the dongle will flash blue and red.
 - 2 Turn on Bluetooth mode on your device (under Settings, Connections or similar).



3 Select "iHv115" on your device's menu of Bluetooth devices. When pairing is successful, the LED will glow solid blue. If prompted for a password, enter "0000" on your device. You can now begin to stream audio and calls from your device.



4 For manual pairing or to pair other devices, press and hold the MultiFunction Button for 7 seconds. The earbuds will power on, attempt to autolink to a previously paired device, then enter pairing mode. Pair your device per step 3 above.



SPEAKERPHONE


Press the MultiFunction Button to answer or end a call. Press and hold for 2 seconds to decline/ignore an incoming call.

EAR CUSHIONS



The Bluetooth Wireless Sport Earbuds come with 3 sets of ear cushions to ensure a satisfying fit. If the current ear cushions do not suit you, remove them and replace with smaller or larger ear cushions

Basic Controls



Note: Noise isolation ear buds like the Bluetooth Wireless Sport Earbuds are designed to provide a good seal in your ears and block outside sounds. You should not use noise isolation ear buds in situations that require you to hear outside warning sounds.