


TG534

SPEAKER User Manual




Product specifications:

- BT : 5.3
- Support: L2CAP/A2DP (AVCTP/AVDTP/AVRCP), can receive AUDIO signal and control the AUDIO device, support HSP/HFP(Handsfree profile), Built-in Mic for hands-free phone call
- Working distance: 10M
- SNR: ≥95db
- Battery:3.7V 1200mAh
- Normal volume playing time: 2H
- Speaker driver : Ø52 mm plus*2
- Power : 4Ω/5W*2
- Frequency response: 50 Hz-20KHz
- Unit size: L230*W108*H108mm
- Unit weight:590g
- Charging:5V/500mA

Product Feature:

- 1.Built-in Low-freq radiators, Super dynamic low-frequency sound pressure gain, listening transparent and flexible.
- 2.International advanced BT chip and circuit design techniques, support all BT device ; Can play music after pairing with BT device .for example mobile/ MID/ TV, the working distance is more than 10M.
- 3.with Mic for hands-free phone call function.
- 4,Built-in MP3 decoding,can directly play TF card,USB disk
- 5.Build-in the FM radio module, convenient to auto scan and save radio channels.
- 6.Support AUX IN audio input
- 7.support TWS

key & slot function:



- 1.USB slot: It can decode and play MP3 format audio when put USB card into the slot.
- 2.TF slot: it can decode and play MP3 format audio when put TF card into the slot.
- 3.AUX: it can play audio via 3.5mm AUX cable to audio device
- 4.DC 5V charging slot:use the standard Type-c charging cable for power charging.
- 5.Power switch: long press for "on/off" . when play music(USB card/ TF card/LINE IN/ BT), press short to switch USB/TF/FM /BT.

(switch to "line in" if via AUX cable to audio device).

- 6.When play music , press short for last song, press long to turn down the volume.
- 7.When play music(USB card/ TF card/LINE IN/BT), press short for "play/pause" . under BT mode with mobile paired ,when call coming. press short to answer a call ,press again to hand up. in FM mode, press short to search station automatically, press again to stop searching).Keep the TWS speaker under BT mode without pairing ,press the "play/pause" key for 3 seconds either of the speaker until hear a hint "du du" for TWS mode ,then can pair the mobile.
- 8.When play music, press short for next song, press long to turn up the volume.

NOTE: Under FM mode, put in the AUX cable to get better FM radio station

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.