
# **Bobtot**<sup>®</sup>





Portable Party Speaker


Quick Start Guide


ET510

















**Bobto**t<sup>®</sup>







CHARGE OUT 5V

07-----Party Light Button


10-----Type-C Charge out

08-----DC Input

11-----Mic Input

12-----AUX Input

09-----USB Input



## FCC Warming

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that

### FCC Warming

interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## | | Need help?

#### Customer Care Guide

\*Double-click the "M" button exit TWS Mode.

\*In TWS mode, turn off one of the speaker, both of them are off.

At our company, we strive to provide exceptional customer care to every one of our clients. We believe that building strong relationships with our customers is essential to the success of our business. To help us achieve this goal, we have put together the following customer care guide.

#### Time

We understand that our customers' time is valuable, so we will respond to any inquiries within 24 hours.

#### Feedback

We know that our customers are the heart of our business so we value your feedback. We encourage you to share your thoughts and ideas with us.

#### Solut

If our customers encounter any issues, we will try our best to find a quick and efficient solution that meets your needs.

## Need help?

Here at Bobtot, we take customer care very seriously. Our customers are our first priority, and we are committed to providing the highest quality service.

If you have any questions or concerns, please don't

hesitate to reach out to us. We will be happy to assist you:

Call or Message: +1 888 572 1718 Email: service@bobtot.net

## bobtot.net

 $\hbox{@2024 BOBTOT // Features and specifications are subject to change and or improvement without notice.}$ 

## 技术要求:

- 1. 成品尺寸90\*90mm 展开尺寸: 720\*90mm
- 2.128g铜版纸
- 3. 风琴折,红色虚线为压线无需印刷出来。
- 4. 单黑色双面印刷