
## Back of the EUT



The regulatory label is located under the bottom access panel.

