

E8

USER MANUAL

True Wireless earbuds

Inside the Box:
1.True Wireless earbuds
2.On-the-go Charging Case
3.Micro USB Cable
4.Ear Caps (Size S/M/L)
5.User Manual

x2PCS
x1PCS
x1PCS
x6Pairs
x1PCS

Earbud LED/Built-in Mic
Multi function Button

Charging Port
Charging Case
Power Button

Charging Case LED

Charging Case Port

1

Specification:
1.Bluetooth Version: BT5.0+EDR
2.Support: HSP/HFP/A2DP/AVRCP
3.Transmission Range: 33 feet (If there are no obstructions)
4.Distortion: <1%
5.Earbuds Playback Time: About 3-4 hours
(High quality music and volume may accelerate battery consumption);
6.Earbud Charging Time: 1-1.5 hours;
7.Charging Case Charging Time:1-1.5 hours
8.Earbud Dimension:19*21.5*25mm;
9.Charging Case Dimension: 25*55*61mm
10.Earbud Weight: 5.1g/PC
11.Earbuds Battery Voltage /Capacity: 3.7V/60mAh
12.Charging Case Battery Voltage /Capacity: 3.7V/650mAh

How to Charge?
(Prior to first use- Make sure both the Earbuds and the Charging Case are fully charged.)
●Use the Micro USB Cable to Charge the Charging Case and Earbuds
1.Put the twins earbuds into the charging case, Make sure the Earbuds are in the correct slots in it.
2.Use the Mirco USB Cable to connect the Charging Case Port and the USB Charger should be safety specification charger(DC5V).
3.When you see the Twins Wireless Earbuds Led lights are Red, it shows they are being charged; When you see the Blue Led light of the Charging case is flashing, it shows it is being charged (Check Photo 1)

2

①

4. When you see the 4 Blue led lights of the Charging case are on all the time , it shows the charging case is fully charged (Check Photo 2).

②

5. When you see the Twins Earbuds Led lights are from Red to Disappear, it shows the twins Earbuds are fully charged(Check Photo 3).

③

3

● Use the Charging Case to Charge the Earbuds:
Because the Charging Case is a power bank,after the Charging Case is fully charged, It can charge the Earbuds for 3-4 times Without the Micro USB Cable.
1.Put the twins earbuds into the charging case, Make sure the Earbuds are in the correct slots in it. Then press the charging case power button.
2.When you see the Twins Wireless Earbuds Led lights are Red, it shows they are being charged (Check photo A).

A

Charging case power button

B

4

◆ Note:Please charge the twins earbuds and the charging box at least once every 3 months if you don't use the earbuds for a long time.Please disconnect the charger in time after the charging box is fully charged.

How to Switch On/O fthe Earbuds?
Turn on
Method 1: Take both earbuds out from the charging case, they will turn on and connect with each other automatically
Method 2: When the twins earbuds is power o fstatus, hold down the twins earbuds MFB for 4 seconds
Turn o ff
Method 1: Put the twins earbuds back into the charging case.
Method 2:When the twins earbuds is power on,hold down the earbuds MFB for 4 seconds (LEDs on both earbuds will keep red for 1 second).

Note: If you turn one of the earbud o fwhile both earbuds are paired with your Bluetooth enabled device, the other one will turn o ffat the same time.

How to Pair Twin Earbuds with my phone?
A.Twins Earbuds Mode
Take both earbuds out from the charging case, they will power on and pair with each other automatically.(Flash red and blue light and voice prompt "left channel" &"right channel")
Enable Bluetooth on your device and select "E8R" from list to connect,you will hear voice prompt "pairing successfully" once connected.

5

Note: Once the earbuds paired with your device manually for the first time as described above, they could pair with this device automatically each time in the future as soon as you take them out from the charging case.

If you hear voice prompt "Low battery" from the Host Channel earbud, and turn o fsoon. the Vice Channel earbud has some battery in fact. You may put the Host Channel Earbud back to the charging case for charging, use the Vice Channel Earbud as Mono Earbud Mode.

B.Mono Earbud Mode
◆ Mono mode for Right Earbud
1.Open the lid of the charging case, just take the "R" earbud from the charging case.
2.Open the bluetooth of your device, search and click the model "E8R", the R earbud will connect with your device successfully.
◆ Mono mode for Left Earbud
1.Open the lid of the charging case, just take the "L" earbud from the charging case.
2.Open the bluetooth of your device, search and click the model "E8L", the "L" earbud will connect with your device successfully.

6

◆ Once you let the single earbud connect successfully with your device at the first time, when the second use, the earbud will connect with your device automatically when take out of the charging case.

Note: If you just use left earbud, you can use left earbud to "+" & "-" volume, you need to "play the previous"& "play the next song" by your phone;
If you just use the right earbud, you can use the right earbud to "play the previous"& "play the next song", you need to "+" & "-" the volume by your phone.

Functions	Operations (Twins Mode)
Play/Pause a song	Click once(of any earbud MFB)
Volume +	Quick Double-click L earbud
Volume -	Quick Triple-click L earbud
Next Track	Quick Double-click R earbud
Previous Track	Quick Triple-click R earbud
Answer/End a Call	Click once (of any earbud MFB)
Reject an incoming call	Long Press 2 secs (of any earbud MFB)
Activate Siri	Long Press 2 secs (of any earbud MFB) with "Toot" prompt

7

FAQ
❶: Why the Earbuds Volume is too low ? Even if i have adjusted the earbuds volume to the MAX ? And I have tested iPhone and Android Phones.iPhone can do it, Android can't. Why ?
A: Yes, Android can't do it. Because iPhone and Android are different system protocol, iPhone system can overcome this, but Android can't be consistent. If you are using Android phone, you have double-clicked the "L" Earbud button to the max volume, you still think the volume is a little low, you can try to adjust the volume by your phone. Hope this answer will solve your confusion.
◆ Q:Why my earbuds can't be charged ?
A: When you put the twins earbuds into the charging case, both of the earbuds led light are red, it shows the twins earbuds are being charged.
*Please remember to press the Charging Case Power Button. If one of the earbud led light is none.
Firstly ,Try to wipe the charging contact point and magnet point with alcohol cloth.
Secondly ,Please make sure you have put the earbuds correctly into the charging case. If you placed incorrect, it may affect the contact between the charging port of the earbud and the charging case.Cause the earbuds can't be charged.
Thirdly , After do the above 2 steps, if still not make it, please make the problem video to our official web after sale, we will help you solve it.

8

❶: Why the Earbuds Multi-function Button (MFB) doesn't work to adjust the volume and songs ? and sometimes the music sound cut in and out ?
A: For these 2 issues, Just try to reconnect the bluetooth with your phone.
Please check the following steps:
Firstly ,Please forget all bluetooth device from your phone.
Secondly , Put the twins earbuds into the charging case, take them out of the charging case when you see the earbuds led lights are red.
Thirdly , Once the "R" earbud led light flashes blue and red, "L" earbud led light flashes blue(It shows the earbuds enter into pairing mode), open the bluetooth of your device, search and click the model "E8 R".

◆ Q:Why is there only one earbud with sound after connecting, or both earbuds can't connect with each other when take out of the charging case?
A:For these 2 issues, please try to reconnect the bluetooth with your phone according to the last Q&A firstly. If not make it, You need to reset the twins earbuds to factory setting . The detail process follows:
1.Before using,please make sure the Earbuds are fully charged. Then forget all bluetooth devices on your phone bluetooth menu.
2.Take out of the twins earbuds from the Charging case, hold down the twins earbuds MFB for 5 seconds to turn o fthe earbuds.
Then hold down the twins earbuds MFB for 5 seconds until right earbud flashes red and blue light; left earbud flashes blue light. It shows the twins earbuds pair with each other successfully.

9

3.Enable Bluetooth on your device to pair "E8R",There will be sound in both ears.
For the next time use, the twins earbuds will connect with each other automatically when taking out of the charging case.
(After trying to reset the earbuds pairing,if you still can't let the twins earbuds pair with your phone, please check whether the last step to open the bluetooth of your phone, if you open the bluetooth before, the earbud system may not respond so quickly, please forget the bluetooth from your phone , then open it , try several times, it will make it.)

◆ Q:Why is Bluetooth Earbuds signal direct distance better than the curve ?
A:Because this is a kind of radio wave, it has low transmission power, However, if there is an obstruction ,the signal is not good.

◆ Q:Why is my phone volume and sound clarity different from my friends phone when calling?
A:This depends on each person's individual phone, we have done our best to ensure the sound clarity and volume on many different phones.

◆ Q:Why does the Earbuds become a little warm after using them for a while?
A:Because these Earbuds are completely the in-ear type, the ear space is not large enough for quick heat dissipation, so the earbuds may get a little warm. But you don't need to worry about it, this heat is definitely a human body acceptable temperature.

10

Safety Precautions:
The Earbuds are excellent quality; in order to extent the life of the Earbuds, please make sure of the following instructions :
1.Please keep the device away from extreme heat, humidity, or corrosive environments.
2.Please prevent the device from being struck or dropping, warping, soaking, etc.
3.Please don't dismantile the Earbuds or Charging Case.
4.Please don't overcharge the device for a long time, as that will decrease the battery service life.
5.Please stop using the device immediately if it causes discomfort or pain.
6.Use DC-5V 1A chargers/adapters certified by a regulated manufacturer. Recharging and discharging the headphones repeatedly will lead to decrease in battery performance over time, which is normal for all rechargeable batteries.(Don't press the elastic pin contact point, so as not to cause them to be used properly.)

11

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.