


3.1101.621478.0000000

原材料 机乐堂 (A-US) JR-MI01 浴室防水盒蓝牙音箱 全英说明书 V1.0

材质: 128g铜版纸+正反单色印刷+风琴折







((()

VII. Operation instructions

Previous track:
Click the previous track button

Next track:
Click the next track button

Play/Pause : Click the multifunctional button to pause or play music

Volume up:
 Click or long press the volume+ button

Volume down:
Click or long press the volume- button

VIII. Indicator instructions

Turn on	The ice blue light ring keeps on for 3s
Turn off	The ice blue light ring flashes twice
Ready for pairing	The ice blue light ring breathes quickly
Charging the speaker	During charging, the ice blue light ring keeps on. When fully charged, it will turn off

IX. FAQ

- Q: Why can't the speaker be turned on?

 A: ① Please check whether the speaker is still with power. If not, please charge it for more than half an hour before turning it on. 3 Please long press the power button, if you press it too shortly or at a wrong position, the speaker may fail to turn on.
- A: ① Check whether the speaker is powered on normally and ready for pairing. (Please check it by the indicator light or prompt tone.)
 ② Check whether the speaker is connected to another device. If so, please disconnect with it and make a reconnection again. 3 Turn off the phone's BT function and the speaker, then turn them on again for reconnection. (4) If the speaker still cannot be connected after above operations, you can restore it to factory
- Q: Why does jamming/discontinuity occur when listening to songs?
 A: ① The speaker' signal may be disconnected because of the long distance between the speaker and connected device. Please keep them within 12m distance.
 ② The speaker' signal may be interfered when being used in an environment with strong interference. Please make sure there's no large shield, metal partition or large interference.
- Please make sure the phone's signal and network are in good condition, in case of poor signal or network cache problems, jamming or discontinuity will happen to your speaker.
- Q: Why is the sound of the speaker too low or mute?
 A: ① It may be that the playback channel of the mobile phone is turned off. You can turn on the phone's BT function, click the icon on the right side of connected device and turn on the media
- prione's Bit function, click the icon on the right side of connected device and turn on the medichannel.

 ② Open the "Settings" interface, check if there is a maximum volume limit on the phone.

 ③ The volume up/down control of the speaker and the mobile phone may be operated separately due to different settings of mobile phones (such as Android). Please adjust the volume of both the mobile phone and the speaker according to the settings of the mobile

- A: In case of BT connection, please turn on the output channel of the computer and set the speaker output mode as default mode.
- wny can't the speaker be charged?
 The charging port and cable may not be connected properly, please pull the cable out and plug it in again repeatedly to make sure it is well inserted.
 Please use adapters that conform to national/regional safety standards together with the included charging cable to charge the product. Unqualified or unguaranteed charging cables may damage the speaker.

X. Safety Criteria

- 1. Please follow the instructions, do not disassemble the product or refit it for any reason,

- 5. Do not block the openings of the product, such as charging port, indicator, etc.

 6. Do not use it at high volume levels or for long periods of time to avoid dizziness or hearing
- 7. Do not use it under thunderstorm which may lead to abnormal performance and signal

⚠ WARNING

Correct disposal of used electrical and electronic equipment

图图

FCC NOTE:

- This device complies with Part 15 of the FCC Rules.
- Operation is subject to the following two conditions:
- (I) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
- However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- -- Reorient or relocate the receiving antenna. - Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.