#81182





You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

Pb = Battery contains lead Cd = Battery contains cadmium

Hg = Battery contains mercury

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty:

All Maisto R/C products have a 30 days limited warranty in function and performance. You may receive a new replacement product if the defective product is returned to Maisto freight prepaid and confirmed a factory defective. Maisto's 30 days warranty is limited to factory defects in material and workmanship only. The warranty does not cover unauthorized modification, accidents, abusive use, and consequential damages per our judgment. The warranty is limited to original purchaser with dated proof of purchase only. If you have a problem with our product, e-mail or call customer service first, RA # may be issued if the problem cannot resolved over the phone or email. Return for repair or replacement must be shipped prepaid/postage prepaid and insured, include dated proof of purchase, RA# and brief description of problem. If product is returned without a dated proof of purchase, it will be excluded from the coverage of this warranty. Allow 3 to 5 weeks for delivery of repaired or replacement per Maisto's discretion. Delivery is limited in U.S.A. or Canada only. Warranty is only valid for purchases in U.S.A and Canada only. Check the FAQ section before you return the product to Maisto.

FAQ (Frequently Asked Questions)

1) Why does my vehicle not start? Make sure that the car and transmitter are set to the same channel (A, B or C).

Make sure the transmitter and the vehicle are turned on. Check to make sure the batteries are not drained.

Make sure the batteries are installed per polarity indicators. Make sure all 4 wheels are not obstructed by any foreign objects.

2) Why does my vehicle make unusual noises?

Check to make sure the batteries are not drained. Check to make sure all 4 wheels are not obstructed by any foreign objects.

Check to make sure no foreign object is inside the vehicle.

3) Why the missile can not be inserted into the launcher? Check to make sure the missiles are not being deformed and damaged.

Check to make sure the launcher is not obstructed by any foreign objects.

Check to make sure the missiles are supplied or recommended by the manufacturer. Slightly adjusting the launcher by pressing the shoot button should help to install the missile.

4) What if I'm still having a problem?

Check the FAQ and make sure all attempts have been made to make the unit work.

Check your purchase receipt date and make sure it's within the 30 days warranty period at the time you intend to send it back. Contact Maisto (see below), and tell us the model that you have, the problem(s) you are having, your daytime phone number, and any other information that might be helpful for us to resolve the problem.

If Maisto cannot solve your problem by mail, email or telephone, we will issue a return authorization number so you can return the unit to us for repair or replacement. No returns will be accepted without a return authorization (RA) number issued by Maisto clearly marked on the outside of the package. Pack the unit back in its original box or another box with sufficient protective material, include a copy of your dated store receipt and a description of the problem then send it freight prepaid to the address which we will provide when we issue the RA number.

5) Please refer to FAQ section on our website for more information.

Website: www.maisto.com

customerservice@MayCheongGroup.com

Phone: (909) 357-7988

8:30 a.m. - 5:00 p.m. / Monday-Friday / Pacific Time

Maisto International, Inc., Fontana, CA 92336, U.S.A.



www.maisto.com MADE IN CHINA

Diagram 3 Battery installation

Battery cover

Diagram 4

Eng(R1)

6 x 1.5V "AA"

Power Switch



Warning! Do not aim at eyes or face

Warning! Do not use projectiles other than those supplied or recommended by the manufacturer. To prevent pinch happens, do not grasp the vehicle by hand or other part of human body while vehicle in running or transformation.

Do not operate the remote controller while you are holding the vehicle.

Maisto Radio Control Vehicles

Please keep this owner's instruction manual for future reference.

It contains important information. We reserve the right to improve/revise the product specifications without notice.

WARNING! The antenna wire is not to be inserted into socket outlaets. Class 1 LED Product

Contents:

Vehicle x 1

Transmitter x 1

Antenna Tube x 1

Missile x 8 (5 + 3 spares)

Owner's Instruction Manual x 1

Battery Requirement:

Vehicle: 6 X 1.5V "AA" LR6/R6 batteries

Transmitter: 2 X 1.5 "AA" LR6/R6 batteries

Battery installation for the Transmitter and Antenna Tube installation: (Refer to Diagram 1 & 2)

1. Switch the transmitter power OFF.


Open the battery cover.


3. Install 2 new 1.5V "AA" LR6/R6 batteries with correct polarity (+/-)

as shown inside the battery compartment.

4. Install the battery cover.

5. Insert antenna wire into the antenna tube. Then bend down the exposed wire and insert a cover to the top end of the tube.





MAY CHEONG TOY PRODUCTS FTY. LTD.			DIECUT
Job Item: Q0290/16R3	Finished by: Fang	Date: 2017/06/12	Test No.:
Item No.: #81182 Eng	Check by:	Date:	File Name:

Size: A4_297mm(W) x210mm(H) Color: 1C (Black)

English

Battery installation for the Vehicle: (Refer to Diagram 3)


- 1. Set the "channel & power switch" on the vehicle to OFF position. 2. Use screwdriver to loosen the screw on the battery cover and
- to open the battery cover. (Screwdriver is not included)
- Install 6 new 1.5V "AA" LR6/R6 batteries with correct polarity (+/-)
- as shown inside the battery compartment.
- 4. Install the battery cover and then tighten the screw on the battery cover.

How to play:

- 1. Match the transmitter with the vehicle channel (channel A to A, B to B, C to C)
- 2. Switch the transmitter ON. The transformation button lights up.
- (Refer to Diagram 4) 3. Follow A, B and C below to transform the vehicle, shoot missiles and drive.
- Switch OFF the transmitter and vehicle after playing.

A) Transformation (Refer to Diagram 5)

- -- Press the Transformation button to transform into different modes.
- -- When transform to Fire mode, the LED headlights will light up.



B) Missile installation and launch (Refer to Diagram 6 & 7)


-- Insert 5 missiles into the launcher.


(Missile size: Length: 73.5mm. Diameter: 4.5mm)


- -- Press the shoot button to shoot missiles. (range: 2m)
- -- Do not aim or shoot missiles at persons or animals. -- When inserting missiles, do not directly face the
- firing mechanism, and never have your face directly in front of the firing mechanism.
















C) Movement (Refer to Diagram 8)

-- Push the left / right levers up or down to move the vehicle.









English

Performance Tips:

- Do not drive the vehicle on grass, sand or go through water.
- Do not drive the vehicle in windy or rainy weather. Do not drive the vehicle into any hard object.
- Keep fingers, hair and loose clothing away from the vehicle.
- The operating range can be affected by a variety of factors: a) Weak transmitter or vehicle batteries.
- b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
- 6. Make sure all missiles are securely inserted into the launcher. 7. Remove any foreign object inside the vehicle before transformation each time.
- Outdoor usage is recommended in order to get optimal control range. Remove the package, take out all accessories and assemble the product before giving it to children to play.
- Cautions: 1. Do not aim missiles at face or eyes at any time.

2. Do not use projectiles other than those supplied or recommended by the manufacturer.

- Do not pick up the vehicle while it is in motion. Do not pick up the vehicle by holding the wind shield or the rear wing.
- Do not hold the wheels while the vehicle is moving. Do not bend the wind shield, body and missiles of the vehicle.
- 7. Keep fingers, hair and loose clothing away from the wheels.
- Do not try to transform when there is something obstructing the vehicle. Do not use force to pull missiles out from launcher.
- Missiles must be removed when the vehicle is not in use.

Battery use:

- Alkaline batteries are recommended.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not mix alkaline, standard or rechargeable batteries. Do not mix old and new batteries or different type of batteries.
- Non-rechargeable batteries are not to be charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the product before they are charged.
- Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions. Remove all batteries from the product when not in use for long periods of time.
- Exhausted batteries are to be removed from the product.

Battery change must only be made by adult.

- The supply terminals are not to be short-circuited. 12. Dispose of batteries properly. Do not dispose of batteries in fire - it may cause them to explode or leak causing injury or damage.
- substances and all other used batteries.

Disposal of batteries:

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful

You can hand in your old batteries at public collection points in your area or wherever batteries are sold.