MONSTER®

KEYBOARD AND MOUSE BUNDLE



USER MANUAL BEFORE USING YOUR NEW PRODUCT, PLEASE READ THESE INSTRUCTIONS TO PREVENT ANY DAMAGE.

KEYBOARD SPECIFICATIONS

- -2.4GHz Wireless technology
- -85% ABS + 15 % metal
- -Size: L14.48 x W5.7 x H0.94 (Inch)
- -96 keys
- -Key life: 10 million time
- -Power: 2*AAA dry battery (included)
- -Compatible with Mac and Windows

MOUSE SPECIFICATIONS

- -2.4GHz Wireless technology
- -Size: L 4.25 x W 2.54 x H 1.49 (Inch)
- -6 buttons: left click, right click, scroll, DPI, backward, forward
- -Resolution: 800-1200-1600 DPI
- -Power: 1*AA dry battery (included)
- -Compatible with Mac and Windows

DIRECTION:

-Step 1: Install batteries to keyboard and mouse separately.

-Step 2: Switch mouse on/off button on the bottom to "ON" position.

-Step 3: It's a plug and play device. After plugging receiver to the computer, keyboard and mouse can be used freely.

* When the batteries are running low on the Keyboard, the battery LED indicator found on the top panel will flash. Please replace battery.

Keyboard F1 - F12		two conditions: (1) This device may not cause harmful interference, a
BUTTONS	FUNCTIONS	 (2) this device must accept any interference received including interference that may cause undesired operation. Caution: Changes or modifications not expressly approved by the party responsible for compliance of void the user's authority to operate this device. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment and on, the user is encouraged to try to correct the interference by one or more of the following measure
FN+F1	Media Player	
FN+F2	Volume down	
FN+F3	Volume up	
FN+F4	Mute	
FN+F5	Previous	
FN+F6	Next	
FN+F7	Play/Pause	
FN+F8	Stop	
FN+F9	Internet explorer	
FN+F10	Email	
FN+F11	My computer	
FN+F12	Favorite	Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected. Consult the dealer or an experienced radio/ TV technician for help.

Safety information & specifications



SAVE THESE INSTRUCTIONS **CAUTION:** Do not use this product for any purpose not explicitly specified by Monster®

Lifeworks shall not be held liable for any improper or incorrect use of the Product, any installation of the Product. or any modification of the Product and Lifeworks assumes no responsibility for such improper or incorrect use of the Product, the installation of the Product, or any modification to the Product. In no event shall Lifeworks be liable for any direct, indirect, incidental, special, exemplary, or consequential damages however caused and on any theory of liability, whether in contract, strict liability, or tort (including negligence or otherwise) arising in any way out of the installation of the Product, or improper or incorrect use of the Product or any modification of the Product. This disclaimer of liability applies to any damages or injury, whether based upon breach of contract, tortious behavior, negligence, or under any other cause of action.

Website: www.monsterstore.com Support: support@monsterstore.com Customer Service: 877-543-3540

The M Monster logo, and Powered by Monster are trademarks or registered trademarks trademark. All brands are registered trademarks of their used under license of Monster, Inc. ©2023 All rights reserved. Manufactured, marketed and distributed by Lifeworks Technology Group LLC. under license.



PDF

