





YY2954 PWB Photo

MAIN



ANTENNA





SUB




JACK




USB




TPAD




WPAD




R1



L1



L4



R3

