

The DUT photos



Inner Top View




Inner Top View

The DUT photos




VCR Deck Top View




VCR Deck Bottom View

The DUT photos




Main Board PCB Parts View




Main Board PCB Copper View

The DUT photos



DVD Deck Top View




DVD Deck Bottom View

The DUT photos




DVD Deck Top View (Removed Cover)




DVD Deck Bottom View (Removed Cover)

The DUT photos




Power Board PCB Parts View




Power Board PCB Copper View

The DUT photos




MPEG Board PCB Parts View




MPEG Board PCB Copper View

The DUT photos



AUX front Input Panel & OSD Board PCB Parts View



AUX front Input Panel PCB & OSD Board Copper View

The DUT photos




Top Cover




Inner Bottom/Inner Front

Tuner photos (TMZH2-030A)



Side View



Side View

The DUT photos



Top Cover