




802.11ax-20 MHz(SU) CHANNEL 11, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 11, BAND EDGE




802.11ax-40 MHz CHANNEL 3, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 3, BAND EDGE




802.11ax-40 MHz CHANNEL 3, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 9, CARRIER LEVEL



802.11ax-40 MHz CHANNEL 9, REFERENCE LEVEL



802.11ax-40 MHz CHANNEL 9, BAND EDGE



MIMO-Main Antenna


802.11b CHANNEL 1, CARRIER LEVEL



802.11b CHANNEL 1, REFERENCE LEVEL




802.11b CHANNEL 1, BAND EDGE



802.11b CHANNEL 2, CARRIER LEVEL



802.11b CHANNEL 2, REFERENCE LEVEL




802.11b CHANNEL 2, BAND EDGE




802.11b CHANNEL 3, CARRIER LEVEL



802.11b CHANNEL 3, BAND EDGE




802.11b CHANNEL 3, REFERENCE LEVEL




802.11b CHANNEL 4, CARRIER LEVEL



802.11b CHANNEL 4, REFERENCE LEVEL




802.11b CHANNEL 4, BAND EDGE




802.11b CHANNEL 5, CARRIER LEVEL



802.11b CHANNEL 5, REFERENCE LEVEL




802.11b CHANNEL 5, BAND EDGE




802.11b CHANNEL 11, CARRIER LEVEL



802.11b CHANNEL 11, BAND EDGE




802.11b CHANNEL 11, REFERENCE LEVEL




802.11g CHANNEL 1, CARRIER LEVEL




802.11g CHANNEL 1, REFERENCE LEVEL




802.11g CHANNEL 1, BAND EDGE




802.11g CHANNEL 11, CARRIER LEVEL




802.11g CHANNEL 11, REFERENCE LEVEL



802.11g CHANNEL 11, BAND EDGE




802.11n-20 MHz CHANNEL 1, CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, BAND EDGE




802.11n-20 MHz CHANNEL 11, CARRIER LEVEL




802.11n-20 MHz CHANNEL 11, REFERENCE LEVEL



802.11n-20 MHz CHANNEL 11, BAND EDGE




802.11n-40 MHz CHANNEL 3, CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 3, BAND EDGE




802.11n-40 MHz CHANNEL 4, CARRIER LEVEL




802.11n-40 MHz CHANNEL 4, BAND EDGE




802.11n-40 MHz CHANNEL 4, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 5, CARRIER LEVEL




802.11n-40 MHz CHANNEL 5, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 5, BAND EDGE




802.11n-40 MHz CHANNEL 8, CARRIER LEVEL




802.11n-40 MHz CHANNEL 8, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 8, BAND EDGE




802.11n-40 MHz CHANNEL 9, CARRIER LEVEL




802.11n-40 MHz CHANNEL 9, BAND EDGE



802.11n-40 MHz CHANNEL 9, REFERENCE LEVEL




VHT-20 MHz CHANNEL 1, CARRIER LEVEL




VHT-20 MHz CHANNEL 1, REFERENCE LEVEL




VHT-20 MHz CHANNEL 1, BAND EDGE




VHT-20 MHz CHANNEL 11, CARRIER LEVEL




VHT-20 MHz CHANNEL 11, REFERENCE LEVEL



VHT-20 MHz CHANNEL 11, BAND EDGE




VHT-40 MHz CHANNEL 3, CARRIER LEVEL




VHT-40 MHz CHANNEL 3, BAND EDGE




VHT-40 MHz CHANNEL 4, CARRIER LEVEL




VHT-40 MHz CHANNEL 4, REFERENCE LEVEL




VHT-40 MHz CHANNEL 4, BAND EDGE




VHT-40 MHz CHANNEL 8, CARRIER LEVEL




VHT-40 MHz CHANNEL 8, REFERENCE LEVEL




VHT-40 MHz CHANNEL 8, BAND EDGE




VHT-40 MHz CHANNEL 9, CARRIER LEVEL




VHT-40 MHz CHANNEL 9, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 1, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 2, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 10, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 11, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 11, BAND EDGE



802.11ax-20 MHz(SU) CHANNEL 11, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 3, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 3, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 3, BAND EDGE




802.11ax-40 MHz CHANNEL 4, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 4, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 4, BAND EDGE




802.11ax-40 MHz CHANNEL 5, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 5, BAND EDGE




802.11ax-40 MHz CHANNEL 5, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 7, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 7, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 7, BAND EDGE




802.11ax-40 MHz CHANNEL 8, CARRIER LEVEL




802.11ax-40 MHz CHANNEL 8, REFERENCE LEVEL




802.11ax-40 MHz CHANNEL 8, BAND EDGE




802.11ax-40 MHz CHANNEL 9, CARRIER LEVEL



802.11ax-40 MHz CHANNEL 9, BAND EDGE



802.11ax-40 MHz CHANNEL 9, REFERENCE LEVEL



MIMO-Aux. Antenna


802.11b CHANNEL 1, CARRIER LEVEL



802.11b CHANNEL 1, REFERENCE LEVEL



802.11b CHANNEL 1, BAND EDGE



802.11b CHANNEL 2, CARRIER LEVEL

