


Tenera 2


by LOVENSE

Charging




Once it is fully charged, the solid red light will turn off.

Turning On/Off & Changing setting




Self Cleaning



Turn on to the highest level and submerge in water for 1 minute.

IPX7 Waterproof

Usage



Visit lovense.com for a complete user manual.

Button A: On/Off (hold for 3 seconds) & cycle up through suction modes (one tap).
Botón A: Encender/Apagar (mantenga presionado por 3 segundos) y suba los niveles de succión (presione una vez).
Botão A: Liga/Desliga (segurar por 3 segundos) e avançar para o próximo modo de sucção (apertar uma vez).
Bouton A: Marche/Arrêt (maintenez pendant 3 secondes) et augmenter la puissance d'aspiration (Appuyez une fois).
A-Taste: Ein/Aus (3 Sekunden lang gedrückt halten) und Saugmodus erhöhen (einmal tippen).
Кнопка A: Вкл./Выкл. (удерживайте в течение 3 секунд) и переключение "вверх" между режимами всасывания (одно нажатие).
ボタン A: オン/オフ (3 秒長押し) & 上方向の吸引/パターンの切替 (1 回押す)。

Indicator light
Luz indicadora
Luz indicadora
Voyant lumineux
Kontrolllampe
Индикатор
インディケーターライト

Charging port
Puerto de carga
Entrada do carregador
Port de chargement
Ladeanschluss
Зарядный порт
充電ポート

Button B: Cycle down through suction modes (one tap).
Botón B: Baje los niveles de succión (presione una vez).
Botão B: Voltar para o modo de sucção anterior (apertar uma vez).
Bouton B: Réduire la puissance d'aspiration (Appuyez une fois).
B-Taste: Saugmodus herunterfahren (einmal tippen).
Кнопка B: Переключение "вниз" между режимами всасывания (одно нажатие).
ボタン B: 下方向の吸引/パターンの切替 (1 回押す)。

Loveense Remote

Any LOVENSE toy ...

Any Loveense toy connects directly to PC using a Loveense USB Bluetooth adapter

Download on the App Store
GET IT ON Google Play

Scan the QR code to watch the product instructions.
Escanea el código QR para ver las instrucciones del producto.
Escaneie o código QR para assistir às instruções do produto.
Scannez le code QR pour regarder les instructions d'utilisation du produit.
Scannen Sie den QR-Code, um sich die Produktanweisungen anzusehen.
Отсканируйте QR-код, чтобы просмотреть инструкции по продукту.
QRコードをスキャンしてプロダクト説明動画を視聴しよう!

Warning

- DO NOT boil in water (the battery may explode or water could leak into the toy).
- Keep away from extreme heat or cold.
- Make sure your toy is recharged at least once every six months.
- DO NOT use the toy while charging.
- Please make sure you don't attach the charging cable to any metal or stainless steel materials.
- DO NOT submerge in water deeper than 1 meter when cleaning or during use.

Advertencia

- NO hervir en agua (la batería puede explotar o podría entrar agua en el juguete).
- Mantener la unidad alejada de temperaturas extremas.
- Cargar el juguete por lo menos una vez cada seis meses.
- NO USAR la unidad mientras se encuentra cargando.
- Asegúrese de no sujetar el cable de carga a ningún material metálico o de acero inoxidable.
- NO lo sumerja en agua a más de 1 metro de profundidad al limpiarlo o durante su uso.

Atenção

- NÃO ferver em água (a bateria pode explodir ou a água pode entrar no brinquedo).
- Manter longe do frio e do calor extremo.
- Certificar que o brinquedo seja carregado pelo menos uma vez a em cada seis meses.
- NÃO suar o brinquedo enquanto carrega.
- Certificar que o cabo do carregador não está preso a nenhum material metálico ou aço inoxidável.
- NÃO mergulhar em água com profundidade superior a 1 metro ao limpar ou durante o uso.

Avertissement

- NE PAS faire bouillir dans l'eau (risque d'explosion de la batterie ou de l'eau pourrait pénétrer dans le jouet).
- Assurez-vous que votre jouet soit rechargé au moins une fois tous les six mois.

- Ne pas exposer à une chaleur ou un froid extrême.
- NE PAS utiliser le jouet pendant le chargement.
- Veuillez vous assurer de ne pas attacher le câble de charge à des matériaux métalliques ou en acier inoxydable.
- Ne pas immerger dans de l'eau à plus de 1 mètre de profondeur lors du nettoyage ou pendant l'utilisation.

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction

-- Consult the dealer or an experienced radio/TV technician for help.