80x80mm 成品尺寸 展开图尺寸: 80x560mm 公差:  $\pm 1$ mm

单位:mm

When the indicator light on the device turns from flashing red light to steady green light, the network configuration is complete.



\*Please refer to the specific APP interface if there are any difference.

#### Frequently Asked Questions

### 1 Can I share with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera and control your bulbs, plugs, and other devices. In the app, press the Profile button and click on the "Home Management" button, and you will be able to give or revoke sharing permissions. In order to share, the other user should already have downloaded the app and registered a new account.

#### 2 What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.

#### 3 How many cameras can I control?

TuyaSmart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.

#### 4 My device can't be connected to network with App

- Make sure the device is under the config status (indicator light is flashing
- Make sure the Wi-Fi is available and not too far away from router Make sure the Wi-Fi password you input is correct

#### 5 My device shows offline in my App

- Make sure the device is powered on
- · Make sure the network is stable and the Wi-Fi name and password not modified. If not, add device again,
- If the network is normal, but it's still offline. Check if there are too many Wi-Fi connections. You can restart your router to check the status of the device.
- \* You can find much more useful information in the Help Center on App.
  \* It is recommended that the device be installed at a height below 2M.
- \* Operating temperature -10 ~ 45 € , Operating humidity ≤95% \* Frequency Range: 2.412~2.462GHz, RF Output Power: 17.5 dBm

#### 6 Installation instructions

- 1. Take out all accessories and arrange them in order
- 2. Paste the positioning sticker on the installation area, such as the wall. ceiling or table, and drill 3 holes on the wall with a drill using a diameter of 6mm. Drive in three expansion screws in sequence to fully secure the
- Align the bottom of the camera's main body, and aim to the right angle.
- 4. Then rotate and snap it into the base until it is completely fixed. Insert the Micro-USB end into the camera interface, and connect the USB end to the adapter. Finally insert the adapter into the socket, then the device will run with power supply.

#### **Technical Specifications**

- Audio: Internal Speaker and Microphone
- Storage: supports up to 128G Micro SD card (not included)
- Wi-Fi: IEEE 802.11b/g/n, 2.4GHz(not compatible with 5GHz Wi-Fi networks)
- Power: General 5V Direct Current 1A, symbol "===" means direct current

#### warning

Federal Communications Commission (FCC) Declaration of Conformity

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- and on, the user is encouraged to the processing antenna.

  —Reorient or relocate the receiving antenna.
  —Increase the separation between the equipment and receiver.
  —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  —Consult the dealer or an experienced radio/TV technician for help.

  Padiation Exposure Statement

n Exposure Statement ipment complies with FCC radiation exposure limits set forth for an uncontrolled rolled rolled nent. This equipment should be installed and operated with minimum distance 20cm the radiator and your body.

Declaration Of Conformity European Notice

Hereby, Ningbo Lingzhu Technology CO., Ltd. declares that this product is in compliance with essential requirements and other relevant provisions of Directive 2014/53/EU,2011/65/EU.

This product must not be disposed of as normal household waste, in accordance with EU directive for waste electrical and electronic equipment (WEEE- 2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling

The device could be used with a separation distance of 20cm to the human

**SMART CAMERA USER MANUAL** 

Thank you for purchasing Smart Camera. Get started using your new devices by downloading TuyaSmart, one convenient app that manages everything straight from your phone. Easily connect to your home Wi-Fi and control multiple devices from the touch of your fingertips

#### What's in the Box

- Smart Camera ×1 USB Cable ×1
- User Manual ×1
- Mounting Bracket ×1 \*
- Adapter x1 \* Screw bag ×1 \*
- \*: Different products have different accessories, please refer to physical packing.

## **Get Ready**

- Know your Wi-Fi network and password
   Make sure your mobile device is running iOS® 11 or higher or Android™ 6.0× or higher
- Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect

#### 1 Download the TuyaSmart app from App Store or Google Play.









### 2 Register an account on your TuyaSmart app



STEP 1. Enter your mobile phone number or email address.



STEP 2. Enter the verification code and create a password.

## 3 Plug in

- Press the Reset Button (as Pic 1) for several seconds until camera starts
- Optional: Insert Micro SD card as shown in Pic 1.





# 

Pic 2

# Enter your "Wi-Fi network and password", dick "OK".

- Open TuyaSmart APP, click "+" on the top right corner of the page "HOME", then select "Smart Camera".
  Make sure the indicator light on the device is flashing red quickly, then press "Next Step".



4 Add device



camera. Heard a prompt tone, click "Heard the beep".



Please read the instruction manual carefully before using the product

版本	物料编号	变更者	变更时间	版本升级原因描述
1.0		马何兵	20220901	原始版本

材质	105g铜版纸	客户	D 6-16	智能摄像机	粉料夕软	SC015-WZ2-智能摄像机(云	设计	马何兵
印刷色	四色印刷	1. 1.0	产品名称	(云台机)	物料名称	台机)-中性海外版-说明书		3132
加工工艺	风琴七折页,正反印刷	中性					审核	吴骏
接合方式	/		型号	SC015-WZ2	物料编号		时间	20220901