

vibesonly.com

Size: 3" Length x .75" diameter

Weight: 25g

Materials: High-quality ABS with body-safe silicone detail

Battery: Lithium Ion

Charging Time: 2 Hrs

Vibes Only™

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Lucy 2 Bullet

Instruction Manual

A versatile vibrator to suit your desire

Double your pleasure with two vibrators in one – switch up the sleeves on this petite and powerful bullet to hit your sweet spot.

Why you'll love the Lucy bullet:

- Connects to the Vibes Only app
- Discreet size to get off anywhere, any time
- Versatile sleeves for internal or external stimulation
- Unassumingly powerful
- 3 intensity levels
- 3 vibration patterns
- High quality ABS plastic with body-safe silicone
- Water resistant



Power + Pattern



Connect with
Bluetooth

What's Your Vibe?



Surrounds the clitoris for broader stimulation



Mini-wand head for precise pleasure

Designed for targeted stimulation

Textured pad for extra sensation



For External Stimulation


Finger loop for better control

Hope you're ready, this vibrator only gets better...

Connect to the Vibes Only app to unlock a whole new world of pleasure by controlling your vibrator in the palm of your hand, or give control to your partner. The Lucy 2 works in tandem with the app for a full-blown journey into orgasmic bliss.

Get connected

Scan this code to download the Vibes Only app on your phone.



Start vibing

This vibrator comes partially charged. To get it all the way up, charge before use.



On your device, hold down the power button for two seconds to turn on.

Your Bluetooth will be enabled when the device turns on. The light will flash to indicate it is discoverable.

The app will detect your device. Select it, and your vibrator is synced!



To adjust intensity and patterns manually: Click the button to cycle through the steady speed levels, then the patterns.



Mix it up – use your bullet naked, or slide it into a sleeve to suit your desire.

Power your vibrator

Charging instructions

If your vibrator is feeling a little lowkey, it may be time for a charge.

Due to the unique design, each Vibes Only model charges slightly differently.

First, plug your USB cord into a standard charging block (high-power charging blocks may damage the battery).

Insert the DC jack (long skinny piece) into the small circle opening (tight hole) on the bottom of your vibe. Be gentle, but firm, until it's in as deep as it can go.

The light on your vibrator will flash to indicate that it's charging.

When it is fully gassed up (approx. 2 hrs) the light will change to a steady glow.



Care for your vibrator ...and it will love you back!

Care instructions

We can't recommend using a water-based lubricant enough, such as **Vibes Only Juiced Up**. Avoid using a silicone-based lubricant as this could kill your vibrator.

Remove your sleeve after every use, and wash it with antibacterial soap and water. Wipe down your bullet with soap and a damp washcloth or use a toy cleaner. Dry thoroughly with a clean towel or air dry. Store in a cool, dry place and keep your vibrator away from toys made of other materials. Remember to charge periodically to maintain the battery life.

What not to do

- Submerge the bullet in water.
- Use with oil-based massage oils or lubricants as it may damage the silicone.
- Leave your vibrator in direct sunlight or ever expose it to extreme heat.

Troubleshooting

Your vibrator's light does not pulse when the charger is connected? This could be why:

- Battery is fully charged (go off!)
- Battery is drained and will require several minutes to recognize that it is being charged.
- Charger is not properly connected. Check your charging block and charging pin.

Your vibrator does not connect with your phone when the button is pressed?

- Battery is drained and your vibrator requires charging.
- Make sure you give Vibes Only permission to access Bluetooth on your phone settings.
- The Bluetooth on your phone is not enabled. Make sure to enable, or reset your phone if needed.
- You have exceeded the 10 seconds required for your vibrator to 'find' a device. Reset both your vibrator and your phone by turning off, waiting 30 seconds, then turning on. Now try again making sure your phone has fully restarted, with the Bluetooth switched on.

If you experience any other problems with your Vibes Only product or have any questions regarding operation, visit www.vibesonly.com or please contact help@vibesonly.com.