



NVNT	n20	5745	Ant2	17.70864297
NVNT	n20	5785	Ant1	17.70883087
NVNT	n20	5785	Ant2	17.69623279
NVNT	n20	5825	Ant1	17.73284763
NVNT	n20	5825	Ant2	17.68506321
NVNT	n40	5190	Ant1	36.13232527
NVNT	n40	5190	Ant2	36.16204535
NVNT	n40	5230	Ant1	36.17664027
NVNT	n40	5230	Ant2	36.202984
NVNT	n40	5755	Ant1	36.11894293
NVNT	n40	5755	Ant2	36.11219008
NVNT	n40	5795	Ant1	36.13625355
NVNT	n40	5795	Ant2	36.13257677


OBW NVNT a 5180MHz Ant1




OBW NVNT a 5200MHz Ant1




OBW NVNT a 5240MHz Ant1




OBW NVNT a 5745MHz Ant1




OBW NVNT a 5785MHz Ant1




OBW NVNT a 5825MHz Ant1




OBW NVNT a 5180MHz Ant2




OBW NVNT a 5200MHz Ant2




OBW NVNT a 5240MHz Ant2




OBW NVNT a 5240MHz Ant2




OBW NVNT a 5745MHz Ant2




OBW NVNT a 5785MHz Ant2




OBW NVNT a 5825MHz Ant2




OBW NVNT ac20 5180MHz Ant1




OBW NVNT ac20 5180MHz Ant2




OBW NVNT ac20 5200MHz Ant1




OBW NVNT ac20 5200MHz Ant2




OBW NVNT ac20 5240MHz Ant1




OBW NVNT ac20 5240MHz Ant2




OBW NVNT ac20 5745MHz Ant1




OBW NVNT ac20 5745MHz Ant2




OBW NVNT ac20 5785MHz Ant1




OBW NVNT ac20 5785MHz Ant2




OBW NVNT ac20 5825MHz Ant1




OBW NVNT ac20 5825MHz Ant2




OBW NVNT ac40 5190MHz Ant1




OBW NVNT ac40 5190MHz Ant2




OBW NVNT ac40 5230MHz Ant1




OBW NVNT ac40 5230MHz Ant2




OBW NVNT ac40 5755MHz Ant1




OBW NVNT ac40 5755MHz Ant2




OBW NVNT ac40 5795MHz Ant1




OBW NVNT ac40 5795MHz Ant2




OBW NVNT ac80 5210MHz Ant1




OBW NVNT ac80 5210MHz Ant2




OBW NVNT ac80 5775MHz Ant1




OBW NVNT ac80 5775MHz Ant2




OBW NVNT n20 5180MHz Ant1




OBW NVNT n20 5180MHz Ant2



OBW NVNT n20 5200MHz Ant1



OBW NVNT n20 5200MHz Ant2



OBW NVNT n20 5240MHz Ant1