


140mm


40mm

Remote Control Guide



- 1. Please insert two No. 7 batteries prior to first use**
Open the battery cover by applying pressure and sliding it downward, then insert two No. 7 batteries and reattach the battery/cover.
- 2. Pairing**
From device desktop, enter **Settings > Remote Control and Accessories > Add Accessory**, then follow the on-screen instructions. Once paired, a message will appear on the TV screen to indicate a successful connection.
- Important Reminders:**
*Always keep the firmware of your TV/cable box updated with the latest/most stable version to ensure optimal user experience.

120mm



- Power:** Press once to turn the device on/off, or press and hold to display a list of options such as turning off and restarting the device.
- Google Assistant:** Press and release the button, then speak voice commands to activate the Google Assistant feature.
- Apps:** Press to display a full list of apps.
- Home:** Press to open Android TV homepage.
- Back:** Return to previous page.
- Shortcut key for Netflix:** Press to open Netflix homepage.
- Shortcut key for Live:** Press to open Live TV homepage.
- Direction:** Move the cursor up, down, left, or right.
- Confirm:** Confirm the current selection.

145mm



Pantone 1505U



Pantone Cool Grey 10U



版本号		设计于	日期
项目名称	语音体感遥控器说明书印刷图纸		20150901
项目号			
零件名称		检查于	日期
零件号			20150901
材料		批准于	日期
工艺	Pantone色印刷		
尺寸			