

### **DC Voltages and Current**

Downlink Amplifier      DC Voltage: 14V  
                                Current: 3A

Uplink Amplifier      DC Voltage: 28V  
                                Current: 0.7A

Preamplifier Step Attenuator      DC Voltage: 14V  
                                Current: 0.2A