

Version: V10

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference. received, including interference that may cause undesired operation

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferenceto radio or television reception. which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


-Reorient or relocate the receiving antenna.

·Increase the separation between the equipment and receiver.


.Consult the dealer or an experienced radio/TV technician for help Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and

Internet settings



Hardware Connections



Open the browser and enter 192.168.16.1

I See the sticker on the back of the router for the login password



Step 1


| If "Broadband dialing" is detected automatically, please enter the operator provided broadband account and password, then click "Next Step"



password shown on this page)

* This picture is for reference only, the specific interfaces

and buttons are subject to the actual object



Single reset button

Note: "WPS/RST" are small holes for some models

WPS/RST button

尺寸: 160*125mm, 公差: ±3mm

Short press 1 to 2 seconds for WPS connection, long press 10 to 15 to restore factory Settings

材质: 80g书写纸+正反面单色印刷

备注: 不需要折叠

日期: 2022.11.11

料号:

描述:

