

ECLIPTIC

WIRELESS HEADPHONES

INSTRUCTION MANUAL



Table of Contents

1 Introduction	1
2 Packaging Contents	2
3 Connection Diagram	2
4 How To Use	3
4.1 General Function	3
4.2 Pairing To Mobile Phone	4
4.3 Charging Your Product	5
5 Product Specification	6
6 FAQ	6
7 FCC Statement	7
Battery Statement	8

1. Introduction

Congratulations, and thank you for choosing the Ecliptic Wireless Headphones. This manual will help you operate Ecliptic Wireless Headphones, but firstly you should familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Ecliptic Wireless Headphones.

Safety Rules

1. Please follow the rules specified in this manual closely to ensure your safety. Before using the Bluetooth headphones, we would strongly encourage you to read through this user manual.
2. Do not wear any of any origins, uneven surfaces, make-ups, accessories and so forth on your face to prevent any possible injury or damage.
3. Do not modify, repair or reassemble the Bluetooth headphones. Doing so may result in fire, electric shock, damage breakdown of the Bluetooth headphones etc. All are not covered under warranty.
4. Do not use an altered or variable input to obtain the Bluetooth headphones.
5. Do not use the Bluetooth headphones in a hazardous location.

2. Packaging Contents



1 x Instruction Manual

3. Connection Diagram



4. How to use

4.1. General Functions

Desired Result	Required Action
Turn on & Enter the pairing mode	Press and hold the On / Off button for 3 seconds. After turning on, the LED indicator flashes red/blue.
Pairing	Put a mobile phone with Bluetooth function or other Bluetooth device to perform discovery pairing. After pairing, the LED indicator slowly turns with light.
Turn off	Press and hold the On / Off button for 3 seconds.
Charging	Plug the Micro USB plug to the Micro USB port. When charging, the LED indicator turns red. After full charging, the LED indicator turns off.
Answering a Call	Press On / Off button to answer phone call, press On / Off button again to end call. Press and hold 3 seconds to reject call. (Works only in mobile phone call).
Play / Pause Music	Press On / Off button to play music and press it again to pause music.
Play Next/ Volume +	Long press Play Next/Volume+ button for volume up. Short press Play Next/Volume+ button for next track.
Play Previous/ Volume -	Long press Play Previous/Volume- button for volume down. Short press Play Previous/Volume- button for previous track.

4.2. Pairing to Mobile phone or other device
To use your Bluetooth headphones, you must first pair your headphones with a mobile phone or other Bluetooth device. Once your Bluetooth headphones is paired to a specific mobile phone, they will remain paired and automatically recognize each other whenever they are within range.

Pairing to a phone and Entertainment:

- Turn on your phone and ensure the Bluetooth function is activated.
- Turn on the headphones, enter the pairing mode.
- Search your Bluetooth devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few seconds the phone will list the "BT ECLIPTIC HP" as a discover device. Select it and follow your phone's instructions to select this pairing.
- Your phone will confirm the pairing, and then press "Yes/OK".

4.3. Charging your headphones

⚠ For your safety, please always use an appropriate 5V input charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

Use the Micro USB Charging cable accessory provided with this headphones. Connect the Micro USB plug to the Micro USB charging port on the headphones positioned at ① in headphones diagram on page 2. Connect the USB plug to a USB port on a computer or wall adapter to activate charging.

**Make sure to keep the headphones charging for a minimum of 2 hours before initial use.



Warning

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones. It is not recommended for more than 6 months.

5. Product Specification

Driver Diameter: 40 mm
Impedance: 32 Ohms
Frequency Response: 20 Hz - 20 KHz
Sensitivity: 100 dB +/- 3 dB
Power Supply: Li-ion Battery 3.7V 160 mAh
Playing Time: 2 - 4 Hours
Charging Time: 2 - 3 Hours
Bluetooth Range: 10 m

Micro USB Charging Cable Included

6. FAQ

1. Why is there no power when the headphones is turned on?
Ans: Ensure the battery has been charged up to 2 hours for initial use.
2. There is no sound when playback.
Ans: Check the connection between headphones with phone is correct. If the connection is not established, please connect again. Make sure the headphones is paired and connected with your target phone or other media device.

7. FCC Statement

FCC STATEMENT
1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential environment. The equipment generates and can receive radio frequency energy and, if not handled and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a different branch circuit than the receiver is connected.
-Consult the dealer or an experienced radio/television technician for help.

RF warning statement

The device has been evaluated to meet general RF exposure requirements. No change can be used to provide exposure condition without restriction.

⚠ Safety instructions for the lithium battery and charging the product

The input voltage to this product is 5V DC. In order to charge the product in safe manner and stable condition, please only use a certified appropriate charger/adapter for charging the product. Only charge the product at ambient temperatures between 10 deg. C to 30 deg. C and 40 deg. C to 50 deg. C. Do not charge above 10 deg. C to 10 deg. C. Do not charge in sunlight or direct heat. Caution of the product after use: Please note that we won't take any responsibility for any wrong operation (eg. voltage higher than 5V), as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. In extreme cases, abuse or misuse of lithium battery pack can lead to explosion, heat generation, fire development or similar development.



FCC ID: 2ACMS-4HP-0682

Manufactured by: 1818 Electronics, Inc.
221 Huxford Street, Suite 202
Hoboken, NJ 07030

Please do not attempt information for future reference