



60S Manual



- | | |
|---|-----------------------------|
| ① | Mesh Intercom antenna |
| ② | Headlight |
| ③ | Headlight button |
| ④ | Mesh Intercom button |
| ⑤ | Status LED |
| ⑧ | Dynamic motion LED |
| ⑦ | Jog dial |
| ⑨ | Speaker and microphone port |
| ⑩ | Charging port |
| ⑪ | Charging LED |
| ⑫ | Phone button |



Charging

Red LED: Charging

Blue LED: Fully charged

Power On/Off

On : Press and hold the Jog Dial and Phone Button for 1 sec.

Off : Tap the Jog Dial and Phone Button.

Volume Adjustment

Rotate the Jog Dial clockwise or counterclockwise

Phone Pairing

1. There are three ways to enter the phone pairing mode.

1) The first time you turn on the 60S:

- Press and hold the Jog Dial and Phone Button for 1 second.

2) Starting with your 60S powered off:

- Press and hold the Jog Dial and Phone Button for 5 seconds.

3) Starting with your 60S powered on:

- Press and hold the Phone for 5 seconds.

2. Select the 60S in the list of the devices detected on the phone.

Music Operation

Play or pause music: Press and hold the Jog Dial for 1 second.

Track back/forward: Rotate while pressing the Jog Dial clockwise or counterclockwise.

Mobile Phone Call Making and Answering

Answering a call: Tap the Phone Button.

Ending a call: Press and hold the Phone for 2 seconds.

Call a Voice Assistant : Tap the Phone Button.

Rejecting a call: Press the Phone Button for 2 seconds.

Speed dial:

- 1) Enter into the Speed Dial : Double tap the Phone Button
- 2) Navigate : Rotate the Jog Dial clockwise or counterclockwise.
- 3) Proceed : Tap the Phone Button.

Mesh Intercom

Mesh Intercom On : Tap the Mesh Intercom Button.

Mesh Intercom Off : Tap the Mesh Intercom Button.

Mute/Unmute the Mic : Press the Mesh Intercom Button for 1 seconds.

Channel Setting :

1. Enter the Channel Setting : Double tap the Mesh Intercom Button.
2. Navigate: Rotate the Jog Dial clockwise or counterclockwise.

3. Save the channel : Tap the Jog Dial Button.

Bluetooth Intercom

Intercom Pairing :

Press the Jog Dial of two headsets for 5 seconds until red LEDs of both units start to flash rapidly.

Intercom Start/End : Tap the Jog Dial.

FM Radio

FM Radio On/Off : Press the Phone Button for 1 second.

Troubleshooting

Factory Reset

If you want to restore the 60S ME to factory default settings, use the Factory Reset.

1. Press the Jog Dial for 10 seconds.
2. Rotate the Jog Dial clockwise or counterclockwise until you hear the voice prompt, "Factory reset".
3. Tap the Phone Button.

Factory Reset

Press the Jog Dial and Phone Button for 10 seconds.

Certification and Safety Approvals FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1)

This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antennae
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Exposure Statement

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. When equipped, the distance between antenna and one's head surface is 47.4mm.

FCC Caution

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void user's authority to operate the equipment.

Industry Canada(IC) Statement

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC RF Exposure Statement

Cet équipement est conforme aux limites d'exposition aux radiations de la FCC/IC définies pour un environnement non contrôlé. Les utilisateurs finaux doivent suivre les instructions d'utilisation spécifiques pour satisfaire à la conformité d'exposition RF.

Lorsque équipé, la distance entre l'antenne et la surface de la tête est de 47.4mm.