


QUICK START GUIDE

TUNE760 NC


BC

HARMAN

WHAT'S IN THE BOX



MANUAL PAIRING



POWER OFF



MANUAL PAIRING MODE

CHOOSE "JBL TUNE760NC" TO CONNECT

BUTTON COMMAND



SIRI®/GOOGLE ASSISTANT/BIXBY

>2s



×1



×1



>2s




>2s




×1



×1



WIRED LISTENING



MULTI-POINT CONNECTION



* (MAXIMUM 2 DEVICES)

ENTER PAIRING MODE WITH THE 2ND DEVICE


- 1 TO SWITCH MUSIC SOURCE, PAUSE THE MUSIC ON THE CURRENT DEVICE AND SELECT PLAY ON THE 2ND DEVICE.
- 2 PHONE CALL WILL ALWAYS TAKE PRIORITY.
- 3 IF ONE DEVICE GOES OUT OF BLUETOOTH RANGE OR POWERS OFF, YOU MAY NEED TO MANUALLY RECONNECT THE REMAINING DEVICE.
- 4 SELECT "FORGET THIS DEVICE" ON YOUR BLUETOOTH DEVICES TO DISCONNECT MULTI-POINT.



1ST BLUETOOTH DEVICE



CHOOSE "JBL TUNE760NC" TO CONNECT



2ND BLUETOOTH DEVICE




CHARGING



CHARGE



LED BEHAVIORS



TECH SPEC

Model:
Driver size:
Power supply:
Weight:
Headset battery type:
Charging time:
Music play time with BT on and ANC on:
Music play time with BT on and ANC off:
Frequency response:
Impedance:
Sensitivity passive mode:
Sensitivity active mode:
Maximum SPL:
Microphone sensitivity:
Bluetooth version:
Bluetooth profile version:
Bluetooth transmitter frequency range:
Bluetooth transmitted power:
Bluetooth transmitted modulation:
Maximum operation temperature:

TUNE760NC
40 mm Dynamic Driver
5V ~ 1 A
220 g / 0.485 lbs
Polymer Li-ion battery (610 mAh / 3.7V)
< 2 hrs from empty
35 hrs
50 hrs
20 Hz - 20 kHz
32 ohm
103 dB SPL/1 mW
95 dB SPL/1 mW
95 dB
-30 dBV/Pa
5.0
A2DP 1.3, AVRCP 1.5, HFP 1.6
2.4 GHz - 2.4835 GHz
< 10 dBm
GFSK, n/4 DQPSK, 8DPSK
45 °C



