

Tel: +886 2 26099301 Fax: +886 2 26099303

B.1 Conducted Emission Measurement



FRONT VIEW



BACK VIEW





Tel: +886 2 26099301 Fax: +886 2 26099303


B.2 Radiated Measurement at Chamber

Frequency Range 9kHz to 30MHz


Charge Mode & Transmit Mode (Via AC Adapter)









Tel: +886 2 26099301 Fax: +886 2 26099303





Transmit Mode - Test Position: Side







Tel: +886 2 26099301 Fax: +886 2 26099303

Frequency Range 30MHz to 1GHz

Charge Mode & Transmit Mode (Via AC Adapter)












Tel: +886 2 26099301 Fax: +886 2 26099303





Transmit Mode - Test Position: Side





Tel: +886 2 26099301 Fax: +886 2 26099303

B.3 RF Measurement



