

XCam Anywhere™ Indoor/Outdoor Color Video Camera

(with built-in 2.4 GHz transmitter)

- **Extremely small size.**
- **Built-in 2.4 GHz Video Sender.**
- **Powered from a plug-in power supply (included).**
- **Use it outdoors to monitor your front door, back yard, etc.**
- **Use it indoors to monitor a child's bedroom, etc.**

Model XX10A

The XX10A is a very small and compact color video camera with built-in 2.4 GHz Video Sender. It is powered from a plug-in power supply (included). You can attach it to that wall anywhere you want to monitor. The XX10A transmits video and sound to the VR30A 2.4 GHz receiver (sold separately) which is connected to your TV located somewhere else in your home (up to 100 ft. away).

1. Refer to the setup and operating instructions that came with the 2.4 GHz Video Receiver, Model VR30A (sold separately) to set up the Receiver.
2. Mount the camera in a suitable location observing the direction arrow so the camera is the right way up. If you install it outdoors, run the small cable adapter through a hole in the wall so you can plug the power supply into an AC outlet indoors.
3. Plug the power supply's jack into the adapter cable on the camera.
4. Plug the power supply into any 120V AC outlet.
5. Set the channel switch on the camera to the same setting as the one on the VR30A Video Receiver.
6. Adjust the antenna on the camera if necessary to aim it in the direction of the VR30A Video Receiver that you have connected to your TV or monitor.

X10 (USA) INC. LIMITED 1-YEAR WARRANTY

X10 (USA) Inc. warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 (USA) Inc. agrees to repair or replace, at it's sole discretion, a defective X10 product if returned to X10 (USA) Inc. within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Call 1-800-675-3044 or e-mail sales@x10.com for details on how to return your unit(s).
2. Enclose a check for \$4.00 to cover postage and handling.
3. Enclose a dated proof of purchase.
4. X10 is not responsible for shipping damage.
Units to be returned should be packed carefully.
5. For additional warranty information, contact X10.

F.C.C. CAUTION - THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION. **NOTE:** NO CHANGES OR MODIFICATIONS MAY BE MADE TO THE UNITS. ANY CHANGES MADE TO THE UNITS WILL VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

