






LCD FRONT







Main Board FRONT




Main Board REAR




Finger Scanner Board FRONT




Finger Scanner Board REAR




Finger Scanner Sub Board FRONT



Finger Scanner Sub Board REAR



Keypad board FRONT



Keypad board REAR