








802.11ax (20MHz) / 6855MHz / Chain A / NSS-4




802.11ax (20MHz) / 6855MHz / Chain B / NSS-4



802.11ax (20MHz) / 6855MHz / Chain C / NSS-4





802.11ax (20MHz) / 6855MHz / Chain D / NSS-4




802.11ax (20MHz) / 6875MHz / Chain A / NSS-4


802.11ax (20MHz) / 6875MHz / Chain B / NSS-4




802.11ax (20MHz) / 6875MHz / Chain C / NSS-4




802.11ax (20MHz) / 6875MHz / Chain D / NSS-4



802.11ax (20MHz) / 6895MHz / Chain A / NSS-4





802.11ax (20MHz) / 6895MHz / Chain B / NSS-4




802.11ax (20MHz) / 6895MHz / Chain C / NSS-4


802.11ax (20MHz) / 6895MHz / Chain D / NSS-4




802.11ax (20MHz) / 7015MHz / Chain A / NSS-4




802.11ax (20MHz) / 7015MHz / Chain B / NSS-4



802.11ax (20MHz) / 7015MHz / Chain C / NSS-4





802.11ax (20MHz) / 7015MHz / Chain D / NSS-4




802.11ax (20MHz) / 7095MHz / Chain A / NSS-4


802.11ax (20MHz) / 7095MHz / Chain B / NSS-4




802.11ax (20MHz) / 7095MHz / Chain C / NSS-4




802.11ax (20MHz) / 7095MHz / Chain D / NSS-4



802.11ax (40MHz) / 6125MHz / Chain A / NSS-4





802.11ax (40MHz) / 6125MHz / Chain B / NSS-4




802.11ax (40MHz) / 6125MHz / Chain C / NSS-4


802.11ax (40MHz) / 6125MHz / Chain D / NSS-4




802.11ax (40MHz) / 6245MHz / Chain A / NSS-4




802.11ax (40MHz) / 6245MHz / Chain B / NSS-4



802.11ax (40MHz) / 6245MHz / Chain C / NSS-4



802.11ax (40MHz) / 6245MHz / Chain D / NSS-4



802.11ax (40MHz) / 6405MHz / Chain A / NSS-4

802.11ax (40MHz) / 6405MHz / Chain B / NSS-4