

MIRROR FEATURES

- · Main mirror rotates 360°.
- · Front of main mirror features a distortion-free 1x reflection.
- · Rear of main mirror features 5x magnification.
- · Magnetic mini mirror features 10x magnification.
- \cdot Mini mirror can be used separately or magnetically attached towards the top or bottom of the main mirror

BULT-IN SPEAKERS

9-INCH LED MIRROR WITH


GNUOS YTINAV

MTOIDUTSAGS

SHARPER IMAGE®

Tip: For secure attachment in any position, peel the film from the gel pad on the back

of the mini mirror and then press the mini mirror firmly in place. If the gel pad loses adhesion, rinse it with water and allow it to air-dry before reattaching



CONGRATULATIONS ON

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no augrantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG. Inc.



Printed in China.

1-800-374-2744.

WODEF NO: 1012867

FOR CUSTOMER SUPPORT, PLEASE CALL

TRADEMARKS. DISTRIBUTED BY AND © 2022

information for future reference.

SPASTUDIO) ARE TRADEMARKS OR REGISTERED

THE 77 LOGO, TOMORROW'S TOMORROW, AND

nse. Keep this manual as it contains important Please read all instructions and warnings prior to

. GNUOS YTINAV M'OIGUTSAGS

JOUR PURCHASE OF THE

SHARPER IMAGE® NAME AND LOGOS (INCLUDING

MERCHSOURCE, LLC. IRVINE, CA 92618. ALL RIGHTS

BESEBAED:


CONTENTS


- SpaStudio™ Vanity Sound
- AC adapter
- 10x magnifying mirror











POWER

The Vanity Sound can be powered by the built-in rechargeable battery and used wirelessly, or it can be directly powered using the included AC 12V USB-C adapter

- 1. Locate the USB-C input on the rear of the Vanity Sound base. The port is the middle
- 20. Plug the 12V USB-C side of the power cable into the port.

 IMPORTANT: The adapter is designed only to be used by the Vanity Sound. Do not
- use it to directly power other devices.

 3. Plug the adapter end of the cable into a wall outlet. The red LED on the front of the
- Vanity Sound will light up when charging and turn off once finished.
 To charge another device from the Vanity Sound, plug a USB-C power cable (not included) into the USB-C output port on the rear left of the Vanity Sound base and then connect the device you want to charge. The Vanity Sound provides
- pass-through charging when plugged into a wall outlet.

 To power a device when the Vanity Sound is unplugged but the internal battery is charged, connect the device to the USB-C output port on the rear left of the Vanity Sound base and then power on the Bluetooth speaker. The Vanity Sound will act as a power bank

HOW TO USE

TURN BLUETOOTH SPEAKER ON/OFF

- 1. To turn on the Bluetooth speaker, press and hold the power button on the rear of the
- To turn off the Bluetooth speaker, press and hold the power button on the rear of the Vanity Sound base. A tone will play indicating it has shut down (Figure A).

TURN LIGHT RING ON/OFF

- To turn on the light ring, press and hold the left dot in the touch bar located on the front of the Vanity Sound base (Figure B).
- To adjust light brightness, swipe across the touch bar or tap to choose from the 3 presets low, medium and high (Figure C).
 To turn off the light ring, long press the left dot in the touch bar (Figure D).

CONNECTING BLUETOOTH

- 1. Turn on the Bluetooth speaker and the Vanity Sound will automatically enter pairing
- 2. On the device you want to pair with the Vanity Sound, select to connect to the "SI Vanity Speaker Mirror 9 Inch" - see your device manufacturer's instructions for pairing your device.

Note: After the initial pairing, the mirror will automatically connect to the device when powered on. A tone will play indicating it has connected.

PLAY MUSIC

- $1. \, {\hbox{\rm Once your device}} \, \hbox{\rm is connected, adjust the speaker volume by turning the control} \,$ knob in front of the Vanity Sound base. Turn the knob clockwise to increase volume
- or counterclockwise to decrease volume (Figure E).

 2. To pause or resume tracks, press the control knob (Figure F).

Note: To search or skip tracks, use your connected device

MAKE CALLS

- To answer an incoming call, short press the control knob (Figure F). The call will be made using the speaker and built-in microphone.
 To end an ongoing call, short press the control knob (Figure F).
 To reject incoming calls, long press the control knob for approximately 2 seconds
- (Figure F).

RECHARGEABLE BATTERY WARNINGS:

- · This product contains batteries that are non-replaceable.
- · There is a risk of fire and personal injury if battery is punctured, damaged, or misused.
- Do not dismantle, crush, incinerate or short-circuit battery.
- · Never expose battery to extreme temperatures or moisture.
- Keep away from flammable materials and direct sunlight.
- Only charge using the provided charger, cable, and/or adapters.
- · Rechargeable battery is only to be charged by an adult.
- · Adult supervision is required while charging the battery.
- Allow battery to cool to room temperature before charging.
- Charge on a non-flammable surface and keep away from flammable products.
- · Discontinue charging if battery becomes hot, swells, smokes, or gives off a strong
- Battery chargers used with the product are to be regularly examined for damage to the cord, plug, enclosure, and other parts. In the event of such damage, chargers must not be used until the damage has been repaired.
- Recycle or dispose of battery according to federal, state, and local laws.
- Keep these instructions for future reference.

SAFETY WARNINGS: PLEASE READ ALL SAFETY WARNINGS **BEFORE USE**

- · Not intended for children under 14 years of age.
- Keep out of reach of children.
- ·Use this product only for its intended use. Do not use attachments of any kind.
- · Use this item has no user serviceable components. Do not disassemble.
- · Do not expose to extreme temperatures or moisture.
- · Keep away from sources of water
- · Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard *immediately*