Connect Box Quick Guide



1 Packing List

Contact your local dealer if the package is damaged or incomplete. The package contents may vary with device model.

No.	Name	Qty	Unit
1	Connect box	1	PCS
2	12V power cable	1	PCS
3	Anti-drop protective case	1	PCS
4	Lanyard	1	PCS

2 Overview

The connect box is intended to improve the installation and commissioning efficiency of cameras, and provide solutions to common construction problems, such as IP address modification, temporary power and network supply, voltage detection, etc. The product features multi-usage, lightweight and easy to carry.

In the actual deployment, the construction personnel can install and test the camera with the LWN-Link Pro app that connects the box, without connecting to the PrC, simplifying and mobilizing the deployment process. For some construction sites without electricity and network, the box can provide temporary power supply and network, so that the camera can get online to help to adjust the installation angle.




NOTE!

- Turn off the box to extend its battery life if you don't use it.
- The battery performance may degrade at low temperatures.

3 Appearance and Interfaces

The appearance and interfaces may vary with device model. The figure below is only for illustration.





NOTE!

- Press the **Reset** button and hold for at least 10 seconds to restore the default Wi-Fi configuration.
- When the power switch is **ON**, long press **O** to turn off the box. Press the button again to turn on the box.



CAUTION!

The DC12V output and PoE output cannot be used at the same time. Otherwise, the connected external devices may be powered off due to insufficient box battery.

4 Device Management

Start up the box

Turn on the power switch to start up the box, and then the system indicator is steady green.

ON/OF



SYS =

Connect network port and DC 12V output

 The power cable supplied with the box and network cable purchased separately are required.

* To supply power to the camera, please connect the network cable to the network port marked with PoE output.





Connect the box Wi-Fi with your phone

View the Wi-Fi SSID on the device label, and connect your phone to the box Wi-Fi.

- Voltage detection: Test the voltage. Range: 0 to 56V.
- PoE test: Test whether the output voltage of the external PoE power supply device is normal. Range: 0 to 56V.
- 12V output: Maximum DC 12V 1A.
- PoE output: Maximum DC 48V 0.25A.



4 Download and install UNV-Link Pro app

Select **Connect Box**, and follow the on-screen instructions to add cameras to the app.



You can adjust parameters of the connected cameras, including changing camera name or password, syncing mobile phone's longitude and latitude to the camera. etc.





NOTE!

The actual operations may be slightly different from the steps in the quick guide as the app may be upgraded or updated. Please follow the on-screen instructions in the app.

Disclaimer and Safety Warnings

About This Manual

- This manual is intended for multiple product models, and the photos, illustrations, descriptions, etc, in this manual may be different from the actual appearances, functions, features, etc. of the product.
- This manual is intended for multiple software versions, and the illustrations and descriptions in this
 manual may be different from the actual GUI and functions of the software.
- Despite our best efforts, technical or typographical errors may exist in this manual.
- Users are fully responsible for the damages and losses that arise due to improper operation.
- Due to such reasons as product version upgrade or regulatory requirement of relevant regions, this manual will be periodically updated.

Disclaimer of Liability

- The product described in this manual is provided on an "as is" basis. Unless required by applicable
 law, this manual is only for informational purpose, and all statements, information, and
 recommendations in this manual are presented without warranty of any kind, expressed or implied,
 including, but not limited to, merchantability, satisfaction with quality, fitness for a particular purpose,
 and noninfringement.
- To the extent allowed by applicable law, in no event shall total liability to you for all damages for the product described in this manual (other than as may be required by applicable law in cases involving personal injury) exceed the amount of money that you have paid for the product.
- Users must assume total responsibility and all risks for connecting the product to the Internet, including, but not limited to, network attack, hacking, and virus.
- To the extent not prohibited by applicable law, in no event will employees, licensors, subsidiary, affiliates be liable for results arising out of using or inability to use the product or service, including, not limited to, loss of profits and any other commercial damages or losses, loss of data, procurement of substitute goods or services, property damage, personal injury, business interruption, loss of business information, or any special, direct, indirect, incidental, consequential, pecuniary, coverage, exemplary, subsidiary losses, however caused and on any theory of liability, whether in contract, strict liability or tort (including negligence or otherwise) in any way out of the use of the product

Network Security

Please take all necessary measures to enhance network security for your device.

The following are necessary measures for the network security of your device:

- Change default password and set strong password: You are strongly recommended to change the
 default password after your first login and set a strong password of at least nine characters including
 all three dements: digits, letters and special characters.
- Keep firmware up to date: It is recommended that your device is always upgraded to the latest version
 for the latest functions and better security. Visit Uniview's official website or contact your local dealer
 for the latest firmware
- The following are recommendations for enhancing network security of your device:
- Change password regularly: Change your device password on a regular basis and keep the password safe. Make sure only the authorized user can log in to the device.
- Enable HTTPS/SSL: Use SSL certificate to encrypt HTTP communications and ensure data security.
- Enable IP address filtering: Allow access only from the specified IP addresses.
- Minimum port mapping: Configure your router or firewall to open a minimum set of ports to the WAN
 and keep only the necessary port mappings. Never set the device as the DMZ host or configure a full
 cone NAT.
- Disable the automatic login and save password features: If multiple users have access to your computer, it is recommended that you disable these features to prevent unauthorized access.
- Choose username and password discretely: Avoid using the username and password of your social
 media, bank, email account, etc, as the username and password of your device, in case your social
 media, bank and email account information is leaked.
- Restrict user permissions: If more than one user needs access to your system, make sure each user is
 granted only the necessary permissions.
- Disable UPnP: When UPnP is enabled, the router will automatically map internal ports, and the system will automatically forward port data, which results in the risks of data leakage. Therefore, it is recommended to disable UPnP if HTTP and TCP port mapping have been enabled manually on your router.
- Multicast: Multicast is intended to transmit video to multiple devices. If you do not use this function,
 it is recommended you disable multicast on your network.
- Check logs: Check your device logs regularly to detect unauthorized access or abnormal operations.
- Isolate video surveillance network: Isolating your video surveillance network with other service networks helps prevent unauthorized access to devices in your security system from other service networks.

- Physical protection: Keep the device in a locked room or cabinet to prevent unauthorized physical access.
- SNMP: Disable SNMP if you do not use it. If you do use it, then SNMPv3 is recommended.

Learn More

You may also obtain security information under Security Response Center at Uniview's official website.

Safety Warnings

The device must be installed, serviced and maintained by a trained professional with necessary safety knowledge and skills. Before you start using the device, please read through this guide carefully and make sure all applicable requirements are met to avoid danger and loss of property.

Storage, Transportation, and Use

- Store or use the device in a proper environment that meets environmental requirements, including and not limited to, temperature, humidity, dust, corrosive gases, electromagnetic radiation, etc.
- Make sure the device is securely installed or placed on a flat surface to prevent falling.
- Unless otherwise specified, do not stack devices.
- Ensure good ventilation in the operating environment. Do not cover the vents on the device. Allow adequate space for ventilation.
- Protect the device from liquid of any kind
- Make sure the power supply provides a stable voltage that meets the power requirements of the
 device. Make sure the power supply's output power exceeds the total maximum power of all the
 connected devices
- Verify that the device is properly installed before connecting it to power.
- Do not remove the seal from the device body without consulting first. Do not attempt to service the product yourself. Contact a trained professional for maintenance.
- Always disconnect the device from power before attempting to move the device.
- Take proper waterproof measures in accordance with requirements before using the device outdoors.

Power Requirements

- Install and use the device in strict accordance with your local electrical safety regulations.
- Use a UL certified power supply that meets LPS requirements if an adapter is used.
- Use the recommended cordset (power cord) in accordance with the specified ratings.
- Only use the power adapter supplied with your device.
- Use a mains socket outlet with a protective earthing (grounding) connection.
- Ground your device properly if the device is intended to be grounded.

Battery Use Caution

- When battery is used, avoid:
- Extremely high or low temperature and air pressure during use, storage and transportation.
- > Battery replacement.
- Use the battery properly. Improper use of the battery such as the following may cause risks of fire, explosion or leakage of flammable liquid or gas.
 - > Replace battery with an incorrect type;
- > Dispose of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery:
- Dispose of the used battery according to your local regulations or the battery manufacturer's instructions.

Avertissement de l'utilisation de la batterie

- Lorsque utiliser la batterie, évitez:
 - Température et pression d'air extrêmement élevées ou basses pendant l'utilisation, le stockage et le transport.
 - > Remplacement de la batterie.
- Utilisez la batterie correctement. Mauvaise utilisation de la batterie comme celles mentionnées ici, peut entraîner des risques d'incendie, d'explosion ou de fuite liquide de gaz inflammables.
- Remplacer la batterie par un type incorrect;
- Disposer d'une batterie dans le feu ou un four chaud, écraser mécaniquement ou couper la batterie:

 Disposer la batterie utilisée conformément à vos règlements locaux ou aux instructions du fabricant de la batterie

Regulatory Compliance

FCC Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- -Consult the dealer or an experienced radio/TV technician for help.

RF Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

LVD/FMC Directive

following measures:



This product complies with the European Low Voltage Directive 2014/35/EU and EMC Directive 2014/30/EU.

WEEE Directive-2012/19/EU



The product this manual refers to is covered by the Waste Electrical & Electronic Equipment (WEEE) Directive and must be disposed of in a responsible manner

Battery Regulation- (EU) 2023/1542



Battery in the product complies with the European Battery Regulation (EU) 2023/1542. For proper recycling, return the battery to your supplier or to a designated collection point.