

MINISO

## EARPHONES USER MANUAL

### 產品使用說明書

#### IN-EAR WIRELESS EARPHONES ÉCOUTEURS SANS FIL INTRA-AURICULAIRE

#### 運動掛脖藍牙耳機

MODEL: TB15

使用產品前請仔細閱讀本使用說明書，並請妥善保管。

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE  
PRODUCT AND KEEP IT PROPERLY.

#### DEAR CUSTOMER

Thank you for using Miniso Wireless Earphones. Please read this manual carefully before use. Use it properly for best product performance. MINISO Wireless Earphones has stylish appearance, compact size, true-to-life sound and multiple functions. The whole series have the patent of appearance design. The system adopting the industry-leading technology enables you to enjoy the excellent sound effects anytime at home, outdoors, during a trip or during work. It provides perfect experience when you play music on your laptops, digital music players and other audio-visual players, leading you to a better life with beautiful music!

#### PRODUCT PARAMETERS


Model: TB15  
Bluetooth Pairing Name: MINISO-TB15  
Bluetooth version: Bluetooth V5.0  
Battery capacity: Lithium battery 3.7V/165mAh  
Audio System: Stereo sound  
Charge Time: Approx. 2 hrs.  
Music Playtime: Approx. 15 hrs. (70% volume)  
Standby Time: 6-7 days  
Supportive Protocols: A2DP,AVRCP,HFP

Input Charging Standard: Micro USB, DC5V / 1A  
Frequency Response: 20Hz-20KHz  
Effective Distance: ≤10 meters

#### CAUTIONS

1. Please control the volume and usage time.
2. Do not use the earphones in potentially hazardous situations.
3. While driving, do not listen to music, make a call or answer a call through earphones. The inability to hear surrounding sounds may present a danger to yourself or others.
4. Keep the earphones out of reach of children to avoid danger caused by improper use.
5. Do not use the product under moisture environment.
6. If discomfort occurs, such as irritation and other symptoms, discontinue use immediately.
7. Do not use or store the product at temperature below minus 15°C or higher than 55°C to avoid shortening its lifespan.
8. Irreplaceable Lithium battery inside.
9. Charge the earphones at least once every three months to prolong the lifespan of the product.

#### PRODUCT OVERVIEW



#### FUNCTIONS

Switch on: Long press the multifunctional button for 3 secs. The indicator light flickers in blue three times.  
Switch off: Long press the multifunctional button for 5 secs. The indicator light flickers in red three times.  
Pairing mode: It enters pairing mode automatically after being switched on, and the indicator light flickers in alternate blue and red.

Successful pairing: The indicator light flickers every 5 secs.  
Answer/Hang up a call: Tap the multifunctional button.  
Reject an incoming call: Long press the multifunctional button for approx. 3 secs.  
Redial the last number that called you: Double click the multifunctional button to redial the last number that called you.  
Last/Next Song: Long press the button (+)/(-) to skip songs.  
Volume up/down: Short press the button (+)/(-) to control the volume.  
Battery level display: It will be shown on the screen if iOS operating system is used on your devices.  
Earphones being charged: The indicator light will be turned on in red.  
Earphones fully charged: The red light will go out, and the indicator light will be turned on in blue.  
Voice assistant: Long press the multifunctional button for approx. 2 secs to activate the voice assistant.

#### ACCESSORIES

Charging cable×1  
Ear tip (L)×2  
Ear tip (S)×2  
User Manual×1

#### TROUBLESHOOTING

1. Fails to pair with the phone.  
Answer: Make sure your earphones are in pairing mode, check in your phone if the Bluetooth is searching for pairing device. Remove the earphones from the list and reconnect with your device again.
2. Cannot turn on the wireless earphones.  
Answer: Check your battery level.
3. Can the battery of the wireless earphones be replaced?  
Answer: No. Lithium-ion polymer battery in the earphones is not removable.
4. Unable to connect the wireless earphones with the phone within 10 meters.  
Answer: Bluetooth is wireless so that it is very sensitive to objects between the earphones and the connected device. Check if there are any metal or other objects that may affect connection within the effective distance.
5. Cannot hear audio playing when the earphones have connected to the computer or the phone.  
Answer: Check whether the computer's audio output is already connected to Bluetooth and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.
6. Can I operate the Apps of my phone through the wireless earphones after connecting the earphones to the phone?

Answer: Some apps may not support being operated through the earphones due to their settings.

FCC Warning:  
This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:  
(1)This device may not cause harmful interference, and  
(2)This device must accept any interference received, including interference that may cause undesired operation.  
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.  
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
--Consult the dealer or an experienced radio/TV technician for help.  
Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.

MADE IN CHINA  
FABRIQUÉ EN CHINE  
صنع في الصين  
HECHO EN CHINA  
www.miniso.com

