




CONSTRUCTION PHOTOS OF EUT



Left Earbud



Brand: SENNHEISER, Model: CX400TW1 L



Black color















Right Earbud


Brand: SENNHEISER, Model: CX400TW1 R
Black color








Earbud (main battery cell)







Charging Case

Brand: SENNHEISER, Model: CX400TW1 C

Black color







Charging case (Main battery cell)



Charging Case
Brand: SENNHEISER, Model: CX400TW1 C
White color
Charging case (alternative battery cell)





Earbud (alternative battery cell)



