




STEREO  
SOUND




When using your Staples Wireless Earbuds, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR EARBUDS.
2. Do not use your earbuds near water. Clean using a dry or slightly moist cloth.
3. Do not place your earbuds on any wet surfaces.
4. Do not allow children or the infirm to play with your earbuds without adult supervision.
5. Do not expose your earbuds to excessive heat, flames or fire.
6. Always press all buttons carefully. Do not manhandle your earbuds.
7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
8. Do not expose your earbuds to temperatures above 40°C. Keep out of direct sunlight.
9. Do not attempt to repair this product yourself. Contact a qualified service center if your earbuds are in need of service.
10. Do not drop, puncture or expose your earbuds to excessive trauma.
11. Your earbuds are not intended for commercial use.
12. Do not place near objects that generate a strong magnetic field.
13. Use only the supplied chargers and cables. Unplug this device when not in use for long periods of time or during lightning storms.



**Bluetooth Specification:** V4.2  
**Frequency Range:** 20Hz-20KHz  
**Supported Profile:** HSP, HFP, A2DP, AVRCP  
**Operation Range:** Up to 33 feet (10 meters)  
**Play Time:** 2-4 Hours  
**Battery Type:** 80mAh Lithium Battery  
**Charge Time:** Approximately 2 Hours



- ① LED Indicator Light
- ② Microphone
- ③ Power / Play / Pause / Answer
- ④ Charging Port

Thank you for purchasing your Staples Wireless Earbuds. Your earbuds are compatible with most iPads, iPhones, iPods, Androids and other Bluetooth compatible devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual prior using.

-Staples Wireless Earbuds

-User's Manual with Warranty Information

Your earbuds have a built-in, rechargeable lithium-polymer battery. To avoid damage, do not attempt to remove the battery. The full performance of the battery is only achieved after two or three charging-discharging cycles. Charge the battery fully before first use. To do so, follow the steps below:

1. Connect one end of the included USB charging cable to the charging port on your earbuds. Then plug the other end of the USB charging cable into a USB port on your computer or a suitable power adapter in order to recharge the internal rechargeable battery.

**NOTE:** The internal battery of your earbuds takes approximately two hours to charge when completely drained.

2. When the battery is charging, the LED indicator light will turn red. The LED indicator light will turn blue when the battery is fully charged.

**NOTE:** Overcharging could reduce the life of the battery. A charged battery will lose its capacity if it is not used on a regular basis.

**Important!**

To avoid a complete discharge of the battery, charge your earbuds at least once every six months.

### Battery Notes

- For best results, charge the battery for three hours before using your earbuds.

Your earbuds can be paired with most Bluetooth devices including iPads, iPhones, iPod Touches, and most smartphones, laptops and tablets. In order to pair your earbuds with a phone, follow the steps below:

1. Press and hold the “POWER” button for three seconds to turn on your earbuds. The LED indicator light will start alternately flashing red and blue repeatedly. This indicates that your earbuds are in pairing mode.
2. Go to the Bluetooth Manager of your Bluetooth device.
3. Search Bluetooth devices and select your earbuds (most frequently listed as “52700-US” )to start connecting.
4. Enter “0000” if your device asks for the PIN code.
5. Once paired, the LED indicator light will slowly blink blue every few seconds.

**Note:** If pairing is not completed within ten minutes, the earbuds will enter standby mode. If this happens, turn the earbuds off and repeat the pairing steps above.

## Powering Your Earbuds On and OFF

1. Press and hold the "POWER" button for three seconds to power on your earbuds. If you have already paired your earbuds to your Bluetooth device, they will automatically remain paired each time you power on your earbuds.
2. Press and hold the "POWER" button for three seconds to power off your earbuds.

## Listening to Music

- **Play/Pause Button:** Press to play or pause a track.
- Note:** You can adjust volume and playback settings on your phone or connected audio device.



### Using the Phone Function

- Answering a Call: Quickly press the ANSWER button to answer an incoming call.
- Ending a Call: Press and hold the ANSWER button to end a call.



-Before using your earbuds, examine the ear cups to make sure that they are clean. Similarly, inspect the ports and jacks of your earbuds to make sure that they are clear of dust and debris before charging.

-Use a soft cloth or paper towel to clean earbuds. Do not allow moisture to get inside the ear cups. Never use any harsh chemicals or detergents for cleaning. Make sure your earbuds are dry before using.

- When your earbuds are not in use, they should be stored in a cool, dry place.

-Never tug or yank on the USB cable while it is connected to your earbuds. Connect and disconnect these cables as carefully as possible.

-Never expose your earbuds to high temperatures, extreme cold, high humidity or excessive moisture or water.

-Please recycle or dispose of your earbuds properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your earbuds for further information.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**The Staples Brand 100% Satisfaction Guarantee**

If you're not 100% happy with this Staples Brand Product, just return it anytime. It's that easy.

Product Support: 1-800-425-0049

**SHENZHEN SHENGLAI TECHNOLOGY CO,LIMITED**

ROOM709,BLOCK B,XINTIAN CENTURY BUSINESS CENTRE,  
FUMING ROAD,FUTIAN DISTRICT,SHENZHEN,CHINA