

USER MANUAL

PROFESSIONAL PORTABLE SPEAKER SYSTEM



PLEASE READ THIS USER MANUAL CAREFULLY BEFORE SYSTEM CONNECTION

IMPORTANT SAFETY MEASURES

Before using this machine, please read all the safety and operating instructions. Please adhere to all the instructions herein, and save this information in a safe place for future use.



1. Please ensure the power cord for this unit is out of the path of foot traffic. Do not place heavy objects on the power cord as it will cause damage to the cord. Always firmly grasp the plug and pull the plug from the power supply, never yank the cable in order to pull out the plug. Avoid the use of an extension cable.
2. Ventilation: This unit should be placed in a well ventilated space where it has no less than 10cm ventilation space on either side of it. Do not cover the unit with a cloth or blanket. Do not put it on a bed, sofa, or carpet as this will stifle the ventilation of the unit.
3. Casing Dismantling: DO NOT dismantle the casing . There are no usable parts inside the unit. Make use of a service center in order to have your unit repaired.
4. Should the unit emit any smell or smoke, immediately turn off the power supply. Take the unit to the service center from which you bought it for repairs.

PRODUCT FEATURES

- Bluetooth&TWS
- Plays Mp3 files stored in SD card/USB drive/external audio device
- FM radio
- Guitar input
- Microphone inputs
- Wireless microphone included
- With remote control
- Built-in rechargeable battery
- Super dynamic sound speaker

1

CONNECTING

1. This set applies to AC 100V ~ 240V, 50/60Hz
2. AC power: battery can be charged when connected to AC power. Red light on battery is charging, it will change to green once battery complete charge.
3. Internal battery will be charged even device switch off when plugged in to AC power
4. Speaker battery can be charged using 12V external car battery as well(connect cable not included) by "DC 12V input". Please make sure "+" and "-" in right connection.
5. Adjust function keys to your personal audio preference.

BATTERY & CHARGING

1. The units takes approximately 8 hours to fully charge. It will automatically begin charging once the power cord is connected.
2. If the battery power is low may caused sound distortion or stop play, please charging the battery on time.
3. To maximize the battery's lifespan, please charging the battery immediately. When the unit is not used for prolonged periods of time,the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30days.
4. To saving battery, please power off once stop using.

BLUETOOTH INSTRUCTION

Change the mode into "BLUE", the bluetooth sign light twinkles, and speaker will give an alarm. Ensure you enable the Bluetooth function on your Bluetooth device. Search for Bluetooth connection until you find device model and pair.

2

TWS CONNECTION

- STEP 1** Push the Mode Button on both speakers until speakers are in Bluetooth Mode. Screen will display the word "BLUE".
- STEP 2** When both speakers are in Bluetooth mode, push and hold the TWS button for 3 seconds. You will hear a beep & screen display "bt/btst". Next time you put both speakers in Bluetooth mode at the same time, speakers will connect automatically.
- STEP 3** On your device, turn your Bluetooth settings "ON", you will then select the unit and pair. Enjoy TWS (True Wireless Stereo) sound from your phone via Bluetooth!


REMOTE CONTROL



- Standby
- USB/SD/LINE (Audio input)
- Prev/FM CH-
- Play/pause/FM tuner
- Next/FM CH+
- Repeat
- Stop
- Volume up
- Volume down
- Mute
- Equalizer
- Number

3

CONTROL PANEL



4

CONTROL PANEL FUNCTION

- ① **POWER** ON/OFF SWITCH
- ② **LED LIGHT** ON/OFF SWITCH
- ③ **POWER INPUT** AC110V-240V INPUT
- ④ **VOLUME**: MASTER VOLUME ADJUST
- ⑤ **X-BASS**: X-BASS ADJUST
- ⑥ **M. ECHO**: ECHO ADJUST
- ⑦ **M. BASS**: MICROPHONE BASS VOLUME ADJUST
- ⑧ **M. TREBLE**: MICROPHONE TREBLE VOLUME ADJUST
- ⑨ **M. VOL**: MICROPHONE VOLUME ADJUST
- ⑩ **GUITAR VOL**: GUITAR VOLUME ADJUST
- ⑪ **MIC. PRI**: MICROPHONE PRIORITY ON/OFF SWITCH
- ⑫ **GUITAR IN**: GUITAR INPUT
- ⑬ **MIC IN**: WIRE MICROPHONE INPUT
- ⑭ **FM** ANTENNA
- ⑮ **USB PANEL** FUNCTION:
 - MODE**: MODE SELECT
 - REC**: RECORD: INSERT THE USB MEMORY/SD CARD AND PRESS THIS BUTTON TO START RECORDING. PRESSING THE BUTTON AGAIN STOPS RECORDING.
 - REPE**: REPEAT A SONG
 - PREVIOUS**
 - SCAN/TWS**: PLAY/PAUSE/TWS; FM STATION AUTO SEARCHING
 - NEXT**
- ⑯ **EQUALIZER**
- ⑰ **DC12V EXTERNAL** INPUT
- ⑱ **AUX INPUT**

5

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.