


Part Name




Requirements

- Requirements**
Please note that Gmail account is required for you to enjoy the full potential of the Xstreamer Wonder system as well as Internet connection for access to Web-based games and services.
- Erforderlich**
Een Gmail-account is vereist om alle gebruiksmogelijkheden van de Xstreamer Wonder en de internettoegang voor Web-gebaseerde services en spellen ten volle te benutten.
- Vereist**
Please note that Gmail account is required for you to enjoy the full potential of the Xstreamer Wonder system as well as Internet connection for access to Web-based games and services.
- Requerimientos**
Se requiere una cuenta de Gmail para poder disfrutar de todo el potencial del sistema de Xstreamer Wonder, así como conexión a Internet para acceder a los juegos y servicios basados en la Web.
- 요구 사항**
Xstreamer Wonder의 다양한 기능을 이용하거나, 웹기반의 게임과 서비스를 위해 Gmail정부가 요구됩니다.


- Требования**
Для того чтобы воспользоваться всеми функциями консоли, вам понадобится аккаунт в Gmail и доступ к Интернету.
- Requirements**
ゲームや一部サービスをご利用いただくにはGmailアカウントが必要です。
- דרישות בסיסיות**
להתאמת מכשירך לשירותי תוכן וחסות האפליקציות עליוך לזיין פרטי חשבון גוגל.
- Persyaratan**
Harap diingat bahwa Akun Gmail diperlukan untuk dapat menikmati potensi penuh dari sistem Xstreamer Wonder dan koneksi internet untuk mengakses permainan dan servis berbasis web.
- 配置要求**
请注意需要Gmail帐号以完美体验Xstreamer BaseCam的各项功能。同时需要因特网连接方可进入网络游戏和服务。
- สิ่งที่จำเป็น**
หากคุณต้องการใช้ Xstreamer Wonder ให้ได้เต็มความสามารถ คุณจำเป็นต้องมี Gmail Account และต้องเชื่อมต่ออินเทอร์เน็ตเพื่อเข้าถึงเกมและบริการต่าง ๆ บนออนไลน์

Setup Wizard



- Setup Wizard**
When you switch your Xstreamer Wonder for the first time, a Setup Wizard will help you to customize the device to uniquely suit your needs.
- Setup Wizard**
Nachdem Sie das BaseCam zum ersten mal eingeschaltet haben, wird ein Setup Wizard starten und Ihnen behilflich sein das Gerät nach Ihrem persönlichen Wunsch ein zu stellen.
- Setup Wizard**
Nadat u uw Xstreamer Wonder voor het eerst aanzet, zal een setup-wizard u helpen het toestel naar uw specifieke wensen in te stellen.
- Asistente de configuración**
Cuando enciendes tu Xstreamer Wonder por primera vez, un asistente de configuración te ayudará a personalizar el dispositivo para adaptarse a tus necesidades de forma exclusiva.
- 설치 마법사**
Xstreamer Wonder 을 처음 연결 시, 설치 마법사가 사용자의 요구에 맞게 장비를 최적화 할 수 있도록 도와드릴것입니다.
- Менеджер Установки**
При первом включении консоли, Мастер Установки поможет вам настроить прибор так, чтобы он полностью удовлетворял ваши потребности.
- Setup Wizard**
세팅업 가이드를 사용하면 사용자와의 취향에 맞게 시스템을 커스터마이징 할 수 있습니다.
- אשף הגדרות**
בדיוקנה הראשונה של המכשיר יצוג בפנך מדריך מקוון שיוביל אותך בעזרת האפסוס של הגדרות המכשיר לעבודה תקינה.
- Ahli Pengaturan**
Apabila Andaeralih ke Xstreamer Wonder untuk pertama kali, sebuah Ahli pengaturan akan membantu Anda untuk menyesuaikan perangkat untuk dapat memenuhi kebutuhan Anda.
- 设置向导**
首次启动Xstreamer BaseCam,设置向导可帮助自定义个性化需求。
- สิ่งที่ต้องจับตามอง**
เมื่อคุณเปิดเครื่อง Xstreamer Wonder ครั้งแรก ตัวช่วยการตั้งค่าจะช่วยให้คุณสามารถปรับการตั้งค่าของระบบให้เหมาะสมกับความต้องการของคุณ

Google Play Store



- Google Play Store**
Xstreamer Wonder is fully compatible with Google Play Store apps. Please note that not all the applications might be suitable for high-definition TV screens.
- Google Play Store**
Den Xstreamer Wonder is 100% compatible mit Google Play Store apps. Achtung bitte: nicht alle verfügbare apps sind ge-eignet für wiedergabe auf HD Fernseher!
- Google Play Store**
De Xstreamer Wonder is volledig compatible met de Google Play Store apps. Gelieve er rekening mee te houden dat niet alle apps geschikt zijn voor HD tv-schermen!
- Google Play Store**
Xstreamer Wonder es totalmente compatible con las aplicaciones de Google Play Store. Por favor, ten en cuenta que no todas las aplicaciones pueden ser adecuadas para las pantallas de television de alta definicion.
- 구글 플레이 스토어**
Xstreamer Wonder은 구글 Play 스토어와 완벽히 호환 합니다. 다만, 일부 어플리케이션의 경우 고화질 TV에 적합하지 않을 수 있습니다.
- Google Play Store**
Xstreamer Wonder совершенно совместима с приложениями из Google Play Store. Однако не все приложения разработаны для телеэкранов.
- Google Play Store**
本機はGoogle Play Storeアプリケーションとの互換性がありますが、全てのアプリケーションへの対応を保証するものではありません。
- חנות האפליקציות של גוגל**
Xstreamer Wonder שפועל שמואם יכולה את חנות האפליקציות של גוגל מותכנת מראש, לתשבות ליכר יתכנן ישומים שכתבה עבור מכשירי חלדור וזם אים מוצגים באופן המותאם לזריחה שבמסךהך.
- Google Play Store**
Xstreamer Wonder sepenuhnya kompatibel dengan Aplikasi dari Google Play Store. Harap diingat bahwa tidak semua aplikasi bisa cocok dengan televisi beresolusi tinggi.
- 谷歌商店**
Xstreamer Wonder完全兼容谷歌商店应用。请注意并非所有的应用都适合高电视屏幕。
- Google Play Store**
Xstreamer Wonder ไม่รองรับการใช้งาน Google Play Store ได้เต็มที่ แต่ต้องแจ้งให้ทราบว่ามีแอปพลิเคชันบางส่วนจะไม่สามารถใช้งานได้ High-Definition TV

Useful Tips

- AirMouse Tips**
Please remember to connect the Air Mouse USB receiver before trying to operate the device. If the LED on the AirMouse is flashing – it's advisable to replace the batteries. Click on the button to switch between the AirMouse and the regular remote control functions. Click on the POWER to put the Wonder on standby. Without operation for about 30 seconds, the AirMouse will enter sleep mode. Press any key to wake it up.
- Settings Tips**
Network – please note that only one network connection is supported at any time so you can only connect to Wired or Wireless LAN.
Display – to adjust the screen to fit your TV, go to Settings -> AV -> Screen Size and use cursor arrows to change values.
Audio setup – to set your desired audio output mode please navigate to Settings -> AV -> Audio Output.
Hide taskbar – to hide the taskbar in the bottom of the Main screen, navigate to Settings -> AV -> Hide Virtual Keys.
- AirMouse Tips**
Bitte zu erst den Air Mouse USB empfänger anschliessen bevor Sie anfangen das Gerät zu benutzen. Wenn der LED am AirMouse blinkt – Batterien wechseln! Drücke die taste zum wechseln zwischen Air Mouse und normales Fernbedienungs-betrieb. Drücke die POWER taste zum schaltet der Wonder im standby. Wenn der AirMouse länger als 30 sek. Nicht bedient wird, schaltet es automatisch zum Sclaf-modus. Zum aufwachen – drücke sonstige Taste.
- Einstellungen Tips**
Netzwerk – Kein Unterstützung für mehrfachen netzwerk-verbindung, das heist: verbindung mit Netzwerk durch WiFi oder Netzwerk-kabel, nicht beides gleichzeitig.
Schirm – Bildgrösse am Fernseher anpassen. Einstellungen -> AV -> Bildgrösse und bediene die Pfeil-tasten zum ändern.
Audio Einstellungen – Um den gewünschten Audio wiedergabe zu ändern: Einstellungen -> AV -> Audio Wiedergabe.
App-menu verbergen – um das App-menu im unteren Teil des Hauptschirms zu verbergen: Einstellungen -> AV -> Verberge App-menu.
- AirMouse Tips**
LET OP! Sluit eerst de Air Mouse USB ontvanger aan voor u het toestel probeert te bedienen. Indien de LED op de AirMouse knipport wordt geadviseerd de batterijen te vervangen. Druk op de knop om te wisselen tussen de Air Mouse en de normale afstandsbedieningsfuncties. Druk op de POWER knop om de Wonder op standby te zetten. Als de AirMouse langer dan 30 seconden niet wordt gebruikt gaat deze automatisch in de slaap-stand. Druk een willekeurige knop om weer te activeren.
- Instellingen Tips**
Netwerk – Er wordt maar 1 netwerkverbinding ondersteund dus u kunt alleen verbinden met WiFi of via network-kabel. Beide gelijktijdig is niet mogelijk.
Scherm – om de beeldgrootte in te stellen op die van uw scherm, ga naar Instellingen -> AV -> Schermafmeting en gebruik de pijltjes-toetsen om de waarden te veranderen.
Geluidinstellingen – om de gewenste geluidinstellingen te veranderen. Ga naar Instellingen -> AV -> Geluidinstellingen.
Taakbalk verbergen – om de taakbalk onderin het hoofdscherm , ga naar Instellingen -> AV -> Verberg virtuele toetsen.
- AirMouse, consolas de utilización.**
Por favor, recuerde que debe conectar el receptor USB Air Mouse antes de operar con el dispositivo. Si el LED en el Air Mouse parpadea es aconsejable sustituir las pilas. Haga clic en el botón de para cambiar entre el AirMouse y las funciones normales del mando a distancia. Pulse POWER para poner el Wonder en modo de espera. Si durante unos 30 segundos no detecta actividad, el AirMouse entrará en modo de reposo. Pulse cualquier tecla para activarlo.
- Configuración**
Red - por favor tenga en cuenta que sólo puede disponer de una conexión de red en cada momento, por lo que sólo puede conectarse a LAN alámbrica o inalámbrica.
Display - para ajustar la pantalla para adaptarse a su televisor, vaya a Configuración -> A / V -> Tamaño de la pantalla y utilice las flechas del cursor para cambiar los valores.
Configuración de audio - para ajustar el modo de salida de audio deseada, vaya a Configuración -> A / V -> Salida de Audio.
Ocultar barra de tareas - para ocultar la barra de tareas en la parte inferior de la pantalla principal, vaya a Configuración -> A / V -> Ocultar teclas virtuales
- Wi-Fi**
Wi-Fi 802.11n
Antenna built-in inside
- USB 2.0 host port x 3**
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical**
Optical
- AV**
AV
- LAN**
LAN
- HDMI**
HDMI
- Micro SD**
Micro SD
- Left, Right, Up, Down**
Left, Right, Up, Down
- OK**
OK
- Play/Pause**
Play/Pause
- Page up/down**
Page up/down
- Home**
Home
- Return/Menu**
Return/Menu
- Right click**
Right click
- Wi-Fi 802.11n**
Wi-Fi 802.11n
- Antenna built-in inside**
Antenna built-in inside
- USB 2.0 host port x 3**
USB 2.0 host port x 3
- Power**
Power
- Optical</**