



5. INNER VIEW OF NOTEBOOK COMPUTER
6. KEYBOARD REMOVE





7. INNER VIEW OF NOTEBOOK COMPUTER
8. INNER VIEW OF NOTEBOOK COMPUTER





9. INNER VIEW OF NOTEBOOK COMPUTER
10. INNER VIEW OF NOTEBOOK COMPUTER




11. INNER VIEW OF NOTEBOOK COMPUTER
12. CHASSIS VIEW





13. FRONT VIEW OF PANEL
14. BACK VIEW OF PANEL





- 15. INNER VIEW OF PANEL
- 16. INNER VIEW OF PANEL





- 17. FRONT VIEW OF TOP CHASSIS
- 18. BACK VIEW OF TOP CHASSIS




19. INNER VIEW OF NOTEBOOK COMPUTER
20. INNER VIEW OF NOTEBOOK COMPUTER



21. FRONT VIEW OF LS-120 & HDD & CD-ROM
22. BACK VIEW OF LS-120 & HDD & CD-ROM





- 27. INNER VIEW OF ADAPTOR
- 28. INNER VIEW OF ADAPTOR




GESTEK 98-F012


- 29. INNER VIEW OF ADAPTOR
- 30. TELEPHONE LINE




31. COMPONENT SIDE OF MAIN BOARD




32. SOLDER SIDE OF MAIN BOARD




33. COMPONENT SIDE OF BATTERY CHARGER & AUDIO JACK BOARD




34. SOLDER SIDE OF BATTERY CHARGER & AUDIO BOARD




35. COMPONENT SIDE OF INVERTOR




36. SOLDER SIDE OF INVERTOR




37. COMPONENT SIDE OF MODEM & CPU CARD



38. SOLDER SIDE OF MODEM & CPU BOARD



39. COMPONENT SIDE OF ADAPTOR



40. SOLDER SIDE OF ADAPTOR

