




Model: H7131



# User Manual

Govee Smart Heater

# Contents

<b>Safety Instructions</b>	<b>01</b>
General Safety	
Power Cord & Plug	
Risk of Leaks & Electric Shock	
<b>Included in the Box</b>	<b>02</b>
<b>Introduction</b>	<b>02</b>
Part Names	
Controls	
Indicator Status	
Functions	
<b>Getting Started</b>	<b>05</b>
<b>Govee Home App</b>	<b>06</b>
Downloading Govee Home App	
Pairing with Govee Home App	
<b>Care &amp; Maintenance</b>	<b>06</b>
Cleaning	
Maintenance	
<b>Troubleshooting</b>	<b>07</b>
For Smart Heater	
For App & Connectivity	
<b>Appendix</b>	<b>09</b>
After-Sales Service	
Specifications	
Compliance Information	

# Govee Smart Heater User Manual

## Safety Instructions

### General Safety

## IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater, or return to authorized service facility for examination and/or repair.
- Do not use outdoors.
- This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to off, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- Faulty wall outlet connections may cause the wall outlet to overheat. Be sure that the heater plug fits tightly into the outlet before using. When using the heater, check to make sure the heater plug is not overheating. If necessary, have a qualified electrician check or replace the wall outlet.
- This heater can only be used when the ambient temperature is normal. When the heater detects that the ambient temperature is too high, it will automatically shut down. Please inspect for any objects on or adjacent to the heater that may casue hight temperatures.
- This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

# SAVE THESE INSTRUCTIONS

## Included in the Box



Item	Quantity
Space Heater	1
User Manual	1
Quick Start Guide	1

## Introduction


Govee Smart Heater is suitable for bedrooms, living rooms, offices, etc. Equipped with PTC heating elements, this smart heater can heat your room quickly in 3 seconds after it is powered on. With one tap in the app, you can adjust the heating based on your needs, bringing instant warmth and maximum home comfort during cold weather.

# Part Names

- A. Cover
- B. Control Panel
- C. Air Outlet
- D. Front Guard
- E. Base
- F. Built-in Handle
- G. Air Inlet
- H. Rear Guard
- I. Power Cord & Plug



# Controls



## Power Button

Touch to power on or off.



## Oscillation Button

Touch to start or stop the oscillation.



## Mode Button

Touch to cycle through Heat Setting I, Heat Setting II, Heat Setting III, ECO Mode, and FAN Mode.

**Note:** Press and hold Power Button and Mode Button for 10 seconds to restore the heater to factory settings and disconnect it from Wi-Fi and Bluetooth.



## Timer Button




Touch to set a timer.



## Night Light Button

Touch to turn the night light on or off.

# Indicator Status

Indicator	Working Status	Light Status
I	Heat Setting I	Solid White
II	Heat Setting II	Solid White
III	Heat Setting III	Solid White
ECO	ECO Mode	Solid White
FAN	Fan Mode	Solid White
	Powered On	Solid Red
	Safety Lock On	Solid White
	Safety Lock Triggered	Flashes White
	Wi-Fi Connected	Solid White
All Indicators	Overheat Protection Triggered	Flashes 3 Times

**Note:** According to related safety standards, the power indicator should always light red when the heater is working.

# Functions

## Memory Function

This heater will memorize the previous settings (heat settings, oscillation, Wi-Fi connection) when it is powered off. The settings will be active again when this heater is turned on.

## 24-hour Automatic Shutdown

This heater will shut down automatically when it has been used for 24 hours straight in case the user forgets to power it off.

## Overheat Protection

When the heater detects that the ambient temperature exceeds 104°F (40°C), it will automatically power off and all its indicators will flash three times. The heater will automatically resume when it detects that the ambient temperature is lower than 104°F (40°C).

**Note:** Overheat protection can be dismissed by unplugging the heater from power and waiting for 30 minutes for it to cool down before plugging back in.

## Tip-over and Motion Protection

When the heater is moved or knocked over, it will automatically power off and stop all functions. This protection can be dismissed by placing the heater on a flat and sturdy surface and keeping it upright before using it again.

**Note:** This heater is embedded with a motion sensor. When it senses tip-over or unintended motion, the heater will automatically shut off.