

Installation instructions




Figure ①

The first installation method, as shown in Figure ①, Cut the magic sticker to an appropriate length, tear off the backing paper and stick it on the dashed line on the back of the boxing target. Then measure the height position and paste another hook and keep on the wall. Finally, stick the boxing target at the hook and keep on the wall, stick it on it and press it hard to complete the installation.

Tip: If the pasted wall is a powder wall, it needs to be pressed flat to make the paste more firm, and the effect will be better if it is left standing for one night. Note that the peeling of the powder wall may lead to slight separation of the powder skin.





Figure ②

The second installation method, as shown in Figure ②, reveal the back suction cup into the keyhole position and press it lightly for installation. Press the boxing target hard and absorb it on the target position until the air in the middle of the sucker is exhausted, and then you can let go. Please choose to attach it to the wall of the tile. Note that the distance between the charging port and the router should not exceed 1.5 meters.

Tip: When installing the sucker, you can clip a little water, which will make the sucker stick more tightly. If you don't use it for a long time, please remove it in time to avoid falling off and hurting.

MUSIC BOXING TARGET

Operation instruction



Please read the instructions carefully before use

Matters need attention

1. Rest for 30 minutes after meals before use;
2. It is not suitable for use when the body is unwell;
3. Electronic products can not be washed with water, but can be wiped with a rag;
4. Charge the machine battery in time after it is dead to prevent the battery from losing power;
5. Stop using it immediately if you feel uncomfortable during use;
6. It is recommended to wear boxing gloves when using;
7. It is forbidden to disassemble the product without permission.

Product introduction

Boxing is a fighting sport, in which two boxers hit each other with gloves on their fists. It is both an amateur and a professional sport. In boxing training, boxing targets are usually used to train the speed and strength of the players. Because the gap of the opponents in boxing matches is feeling, compared with strength boxing, it is more important for the players' offensive and defensive reaction ability. The products train people's reaction ability through electronic control of lighting guidance, and judge whether they hit the target accurately through sound effect prompts, thus effectively exercising people's overall coordination and reaction ability.

Handling instruction



Basic edition



Bluetooth version

- Speed key: Three speeds, short press to adjust.
- On key: Long press the switch, short press the pause.
- Voice key: Long press mute, short press third volume.


- Speed key: Long press to pause, short press the third speed.
- On key: Long press the switch and short press the Bluetooth connection.
- Voice key: Long press mute, short press third volume.

Tip: Bluetooth connection name (gym)

Charging instructions



Charging by connecting wiring with USB charger
Battery capacity: 500mAh



WARNING: CHARGING OR MODIFICATION TO THIS SET NOT SPECIFICALLY APPROVED BY THE FACTORY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S WARRANTY TO REPAIR THE EQUIPMENT. WITH THE EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE UNITED KINGDOM'S SAFETY STANDARDS, PLEASE BE AWARE OF THE FOLLOWING: THESE PARTS ARE DESIGNED TO PROVIDE A REASONABLE PROTECTION AGAINST HARMFUL, INTERFERING ALL RESISTANCE, NOT ELIMINATE THE EQUIPMENT OPERATES, AND THE USER MUST READ THE USER'S MANUAL CAREFULLY. IF NOT FOLLOWED, THE USER IS RESPONSIBLE FOR THE INSTRUCTIONS, BUT ALSO HARMFUL, INTERFERING TO HARM.

COMPLIANCE INFORMATION: THERE IS NO GUARANTEE THAT INTERFERENCE WILL NOT OCCUR IN AN UNUSUAL SITUATION. IF THE EQUIPMENT DOES CAUSE HARMFUL, INTERFERING TO HARM OF TELEVISION RECEIVING, WHICH CAN BE REMEDIATED BY TURNING THE EQUIPMENT OFF AND ON. THE USER IS RESPONSIBLE TO THE USER TO CORRECT THE INTERFERENCE BY ONE OF MORE OF THE FOLLOWING MEASURES: REARRANGE OR RELOCATE THE RECEIVING ANTENNA.

DISCONNECT THE SEPARATION BETWEEN THE EQUIPMENT AND RELOCATE THE EQUIPMENT AND RELOCATE THE SEPARATION BETWEEN THE EQUIPMENT AND RELOCATE THE SEPARATION.

THE EQUIPMENT IS CONNECTED.

CONNECT THE CABLE TO AN APPROPRIATE POWER SOURCE OR BATTERY.

THE DEVICE MUST NOT BE COLLECTED OR REPAIRED OR CHANGED WITHOUT THE USER'S PERMISSION.

FOLLOW THE INSTRUCTIONS FOR THE EQUIPMENT TO BE USED IN COMPLIANCE WITH THE

FACTORY'S REQUIREMENTS. PLACE THE PRODUCT AT LEAST 20CM FROM OTHER DEVICES.