



SMART GRILLING HUB



USER MANUAL

TABLE OF CONTENTS

Box Contents 3

Quick Start Instructions 4

Important Information 13

 Intended Use 13

 Temperature Probe Use 13

 Disposal Requirements 14

 Technical Specifications 14

 FCC Compliance 14

 IC Compliance 14

 IFETEL Compliance 14

Battery Safety Information 15


BOX CONTENTS



Placeholder
for
Charging Cable
Illustration

Charging Cable

Weber Smart Grilling Hub




Placeholder
for
Ambient Clip
Illustration

x2 Temperature Probes

Ambient Grate Clip

QUICK START INSTRUCTIONS


1



Charge your Weber Connect Smart Grilling Hub until the Charge Icon illuminates green.




2



Plug one or more probes into your Smart Grilling Hub to power the unit on.



3



Download the Weber Connect App and make sure WiFi and Bluetooth are enabled in your smart device's settings.




4



Launch the Weber Connect App on your smart device. Follow the pairing instructions within the App.



5




To finalize initial pairing with your smart device, press down on your Smart Grilling Hub when the unit displays all four probe indicator lights.

Note: This step only needs to be performed the first time pairing



6



When meat probes, ensure that the tip of the probe is inserted into the thickest section of the food, avoiding bones or fat.

When using ambient probes, ensure that the provided grate clip is properly secured to the cooking surface.




7



Follow step-by-step grilling instructions in Weber Connect App. Enjoy your meal!




8



After using your Smart Grilling Hub, unplug probes to power the device off.



9



To check battery status of your Smart Grilling Hub, press down on device when no probes are connected.



IMPORTANT INFORMATION

Visit [Weber.com/connectsupport](https://www.weber.com/connectsupport) to find out more about device compatibility, languages supported by the Weber Connect App, a full user guide with great grilling inspiration. Please read the full user guide – especially the safety information – before using the Weber Connect Smart Grilling Hub for the first time, and follow the instructions while using the device.

Intended Use

Use this device only for measuring and monitoring the temperature of grilled items. Any use other than that described may cause damage. The manufacturer or retailer are not liable for damages arising from improper use. When using a Weber Connect Smart Grilling Hub, never leave your grill unattended and follow all instructions in your grill owners guide.

Note: Do not modify/alter Weber Connect Smart Grilling Hub

Note: Do not throw or impact Weber Connect Smart Grilling Hub

Note: Do not submerge Weber Connect Smart Grilling Hub

Note: Do not put Weber Connect Smart Grilling Hub in microwave

Temperature Probe Use



WARNING: Risk of Injury! The temperature probes are very sharp. Please be careful when handling probes.



WARNING: Risk of Burns! Handling the temperature probes without hand protection will result in severe burns. The colored probe indicators are not intended to be touched with bare hands while using the grill as they are not heat insulated. Please wear heat protective gloves while using this product at all times to avoid being burned.

Important Note: When using probes, be sure to route wire where it will not be exposed to flames or temperatures exceeding 716° F (380° C). Avoid exposing probes to temperatures below -22° F (-30° C). Temperatures below -22° F (-30° C) or above 572° F (300° C) will not display in the app and will cause the probe to disappear from connection.

Clean the probes before first use. The probes are not dishwasher safe. Do not use chemicals or abrasive detergents to clean the probes. Wipe them down with a damp towel or cleaning wipe. Take care not to expose the probe's wiring or the area where the wiring meets the probe to liquid.

The probes are not waterproof and damage may result from water exposure. Never submerge the probes in water.



WARNING: Battery Disposal! Never dispose of batteries in an open fire. Always dispose of batteries in accordance with local laws.

Note: The Connect Smart Grilling Hub and batteries are not designed to withstand high heat. If the surface is too hot to touch, it's too hot for the Weber Connect Smart Grilling Hub and batteries.

Note: The device is not to be used by children or persons with reduced physical, sensory or mental capabilities.

Frequency Range (MHz): 2402.0 - 2480.0 MHz

Output Power (Watts): 0.0012 W

FCC Compliance: This equipment has been tested and found to comply with the rules for white space devices, pursuant to part 15 of the FCC rules. These rules are designed to provide reasonable protection against harmful interference. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the manufacturer, dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by Weber could void the user's authority to operate this device.

IC Compliance: This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

IFETEL Compliance: Operation of this unit is subject to the following two conditions: (1) this unit or device may not cause harmful interference, and (2) this unit or device must accept any interference, including interference that may cause undesired operation.

BATTERY SAFETY INFORMATION



Important Safety Instructions and Warnings for Lithium Ion (Li-Ion) Batteries

General Guidelines and Warnings

- You must read these safety instructions and warnings before using or charging your Weber Connect Smart Grilling Hub.
- Li-ion batteries are volatile. Failure to read and follow the below instructions may result in fire, personal injury and damage to property if charged or used improperly.
- Li-Ion battery packs may explode and cause fire if misused or defective.
- Use only the charger supplied with your Weber Connect Smart Grilling Hub. Do not use a NiMH or NiCd charger. Failure to do so may cause fire, which may result in personal injury and property damage.
- Do not charge when room temperature is below 32F(0C) or above 113F (45C).
- If at any time you witness your Weber Connect Smart Grilling Hub starting to smoke while charging, discontinue the charging process immediately, disconnect the battery and observe it in a safe place for approximately 15 minutes. Observation should occur in a safe area outside of any building or vehicle and away from any combustible material.
- Never drop the unit.
- Do not charge the battery in presence of flammable liquids or gases.
- Do not expose the charger to rain or snow.
- Children should be supervised to ensure they do not play with the battery charger.
- Use caution to avoid puncture of the cell. Puncture of cells may cause a fire.

Storage & Transportation

- Store unit at room temperature for best results.
- Do not expose battery pack to direct sunlight / heat for extended periods of time. Any exposure to heat can cause significant damage or fatal injury.
- Storing battery at temperatures greater than 140F (60C) for extended periods of time (more than 2 hours) may cause damage to battery and possible fire.

Voltage, Capacity, Capacity in Watts:

- Voltage: 3.7V
- Capacity: 3.2Ah
- Capacity in Watts: 11.7 Wh



Importado y Distribuido en México por:
Weber-Stephen Products S.A. de C.V.

ANATOLE FRANCE 139-139A
Colonia. POLANCO III SECCION
Del. MIGUEL HIDALGO
CIUDAD DE MEXICO
C.P. 11540

RFC: WPR030919-ND4

Teléfono: 01800-00-WEBER (93237)


Imported by / importé par
WEBER-STEPHEN (CANADA) COMPANY

1 Roybridge Gate
Vaughan, Ontario, CANADA
L4H 4E6

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Weber-Stephen Products LLC is under licence. Other trademarks and trade names are those of their respective owners.

Wifi Trademark/Copyright Copy Placeholder

Wifi Logo Placeholder



R-NZ