



802.11be-EHT160 - Ant 0 (Nss = 1)


Channel 15 (6025MHz)




Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11be-EHT320 - Ant 0 (Nss = 1)

Channel 31 (6105MHz)




Channel 63 (6265MHz)




Channel 95 (6425MHz)




Channel 127 (6585MHz)



Channel 159 (6745MHz)




Channel 191 (6905MHz)




802.11ax-HE20 - Ant 1 (Nss = 1)


Channel 01 (5955MHz)




Channel 45 (6175MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)




Channel 105 (6475MHz)




Channel 113 (6515MHz)



Channel 117 (6535MHz)




Channel 149 (6695MHz)




802.11ax-HE20 - Ant 1 (Nss = 1)


Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 213 (7015MHz)




Channel 229 (7095MHz)




802.11ax-HE40 - Ant 1 (Nss = 1)


Channel 03 (5965MHz)




Channel 43 (6165MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)




Channel 115 (6525MHz)



Channel 123 (6565MHz)




Channel 147 (6685MHz)




802.11ax-HE40 - Ant 1 (Nss = 1)


Channel 179 (6845MHz)




Channel 187 (6885MHz)




Channel 195 (6925MHz)



Channel 211 (7005MHz)




Channel 227 (7085MHz)




802.11ax-HE80 - Ant 1 (Nss = 1)


Channel 07 (5985MHz)




Channel 39 (6145MHz)




Channel 87 (6385MHz)




Channel 103 (6465MHz)




Channel 119 (6545MHz)




Channel 135 (6625MHz)



Channel 151 (6705MHz)




Channel 167 (6785MHz)




802.11ax-HE80 - Ant 1 (Nss = 1)


Channel 183 (6865MHz)



Channel 199 (6945MHz)




Channel 215 (7025MHz)




802.11ax-HE160 - Ant 1 (Nss = 1)


Channel 15 (6025MHz)




Channel 47 (6185MHz)




Channel 79 (6345MHz)




Channel 111 (6505MHz)




Channel 143 (6665MHz)



Channel 175 (6825MHz)




Channel 207 (6985MHz)




802.11be-EHT20 - Ant 1 (Nss = 1)


Channel 01 (5955MHz)




Channel 45 (6175MHz)




Channel 93 (6415MHz)




Channel 97 (6435MHz)




Channel 105 (6475MHz)




Channel 113 (6515MHz)



Channel 117 (6535MHz)




Channel 149 (6695MHz)




802.11be-EHT20 - Ant 1 (Nss = 1)


Channel 181 (6855MHz)




Channel 185 (6875MHz)




Channel 189 (6895MHz)



Channel 213 (7015MHz)




Channel 229 (7095MHz)




802.11be-EHT40 - Ant 1 (Nss = 1)


Channel 03 (5965MHz)




Channel 43 (6165MHz)




Channel 91 (6405MHz)




Channel 99 (6445MHz)




Channel 107 (6485MHz)



Channel 115 (6525MHz)



Channel 123 (6565MHz)



Channel 147 (6685MHz)

