


Attachment A

FCC Diagram Label

Labeling

The switch setting, serial number, and FCC identifier label locations on the back side of the Target are shown in the following drawing.

The Target FCC identifier label is located below the connectors and next to the model/ revision/serial number label.



Target Labeling

Further Information

For additional information on the Target, refer to CTS document 061-9205 which is titled: *GO CARD[®]* System MK5 TARGET DESCRIPTION.