

Model No.: MH22210

BLUETOOTH HEADPHONE

OPEN EAR AC601

QUICK START GUIDE

Please read this Quick Start Guide carefully and keep it for future use.

Product Overview

Open earphones x2 (L & R)

Charging case x1

USB-C cable x1

Quick start guide and warranty card

Charging

Before using the "Monster Open Ear AC601", please connect the USB-C cable to a power adapter to begin charging. Fully charge the earphones and the charging case before the first use.

Power On/Off

When taken out of the charging case, the earphones will turn on and pair with each other automatically. To turn off the earphones, put them in the charging case, then the earphones will be turned off and start charging.

Pairing

The earphones will turn on when taken out of the charging case.

For new device connection, turn on the Bluetooth in your device and choose "Monster Open Ear AC601" from the Bluetooth list to connect. You will hear system prompts after the earphones are connected to the device. If the earphones have been connected before, they will connect to the last connected device automatically after being turned on.

Wearing

Put the "Monster Open Ear AC601" onto your ears and rotate to fit comfortably to get the best wearing and sound quality experience.

MFB Operation

Answer call

Press L or R twice

End call

Press L or R twice

Reject call

Press MFB on the left or right earphone for 2 seconds

LED indicator (earphone)

Power on

The white light is on

Power off

The red light on 2s and then turn off

Pairing is successful

The white light on 1s and then turn off

Pairing timed out

The red light on 2s and then turn off

Connection is over distance

White flashes

Disconnect the phone

White flashes

Low battery

Red light flashes slowly

Low power off

The red light on 2s and then turn off

LED indicator (charging case)

Charging

White light flash slowly

Four white lights are light off when full charged

Discharge

The left 1 light of the left earphone keeps on and goes out when it is fully charged, and the right 1 light of the right earphone keeps on and goes out when it is fully charged

Low battery

The first white light from the left flashes quickly

Reset

In the power on state, touch the MFB of the earphones 5 times (two earphones at the same time), and the earphones will automatically enter the pairing mode to reset.

Attention

*Private replacement of batteries without permission is not recommended.

*Batteries [battery packs or battery combinations] should not be exposed to lighting, baking or similar overheating environments.

*The input voltage and current standard ≤ 5V/1A when charging the headset charging compartment from an external power source;

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
FCC ID: 2AVD2-MH22210

Model No.: MH 22210

OPEN EAR AC601

快速指南

请仔细阅读本快速指南并妥善保存以备将来使用。
本产品由中国平安保险公司承保

产品概述

耳机x2 (左&右耳)

充电盒x1

USB-C充电线 x1

快速指南/保修卡

充电

请在使用此设备前先将耳机和充电仓充满电，此设备可以通过USB-C接口进行充电。

电源开、关

打开充电盒盖，拿出两只耳机，将自动开机。想要关闭耳机，请将耳机放入充电盒，耳机关机同时进行充电。

配对

打开充电盒，拿出两只耳机，它将自动开机。对于新设备连接，请打开蓝牙设备并搜索 " Monster Open Ear AC601 " 进行连接，配对成功后，您会听到系统提示音。
如果耳机之前已配对过，开机就会尝试连接上一次的设备。

佩戴

拿出耳机，将 " Monster Open Ear AC601 " 顺着耳后佩戴，并轻轻旋转至舒适位置，以确保获得最佳的佩戴效果和音质体验。

按键操作

接听

双击左或右耳

挂断

双击左或右耳

拒接

长按左或右耳MFB键2秒

LED 指示灯 (耳机)

开机

白灯亮

关机

红灯长亮2s熄灭

配对成功

白灯长亮1s熄灭

配对超时

红灯长亮2s熄灭

连接超距

白灯快闪

断开手机连接

白灯快闪

低电提醒

红灯慢闪

低电关机

红灯长亮2s熄灭

LED 指示灯 (充电盒)

充电

白灯慢闪

满电4个灯熄灭

放电

左耳机入仓充电对应仓左1灯长亮，满电熄灭；右耳机入仓充电对应仓右1灯长亮，满电熄灭；

低电提醒

左起第1个灯白灯快闪

更多操作

接听

双击左或右耳

挂断

双击左或右耳

拒接

长按左或右耳MFB键2秒

LED 指示灯 (耳机)

开机

白灯亮

关机

红灯长亮2s熄灭

配对成功

白灯长亮1s熄灭

配对超时

红灯长亮2s熄灭

连接超距

白灯快闪

断开手机连接

白灯快闪

低电提醒

红灯慢闪

低电关机

红灯长亮2s熄灭

LED 指示灯 (充电盒)

充电

白灯慢闪

满电4个灯熄灭

放电

左耳机入仓充电对应仓左1灯长亮，满电熄灭；右耳机入仓充电对应仓右1灯长亮，满电熄灭；

低电提醒

左起第1个灯白灯快闪

注意

*不建议未经许可私下更换电池。

*电池[电池组或电池组合]不得暴露在照明，烘烤或类似过热的环境中。

*耳机充电仓在外接电源充电时，输入电压电流标准 ≤ 5V/1A；

封面

75X95MM 105G双胶+1k+1z印刷+风琴折