## SP-0485 Wireless Speaker Manual

Size: H: 100mm x W: 322.5mm

Adobe

5 BASS JANX	Product Overview	Charging your Wireless speaker	<ul> <li>A. Safety instructions for the lithium battery and charging the product         <ul> <li>The input voltage to the product is DC 5V 1A.</li> <li>In order to charge the product in safe manner and reliable conditions, please only adopt             certified appropriate charger/ adapter for charging the product.</li> <li>Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40             deg °C/104 deg °F.</li> <li>Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire.</li> <li>Switch off the product after use.</li> <li>Please note that we won't take any responsibility for any wrong operation (eg. Voltage             higher than 5V) as this may result in severe injury or loss of property, and we cannot             control the operating process during the time the user using this product.</li> <li>In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat</li> </ul> </li> </ul>	NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not
	Front Back	<ol> <li>Use the Micro USB charging cable provided with this wireless speaker.</li> <li>Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.</li> <li>The light will turn red while charging and will turn off once fully charged.</li> </ol>		
SPECTRUM WIRELESS SPEAKER		NOTE: • You must select a qualified charger from a regular manufacturer. • You must charge the Wireless speaker if it has been not used for more than 12 months.		
Instruction Manual	Micro USB Charging port On/Off switch	USB Plug Micro USB Plug		
Thank you for purchasing the Spectrum Wireless Speaker.	Package Contents	Technical Specification	generation, fire development or smoke development.	installed and used in accordance with the instructions, may cause harmful
This manual provides more information about this wireless speaker, please read the instructions before using.	1(One) Wireless Speaker 7 in. x 3.5 in. x 3.1 in. (18 cm x 9 cm x 8 cm) 1(One) Micro-USB Charging Cable 19.7 in. (50 cm) 1(One) Instruction Manual	Driver Diameter : 52 mm Impedance : 4 Ohms Playing Time : 1.5 - 2 Hours Charging Time : 1.5 - 2 Hours Power Supply : Li-lon Battery 3.7V 300 mAh Bluetooth Range : 32.8 feet Micro USB Charging Cable Included		interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the
	Power On/Off			interference by one or more of the following measures:
	<i>Power on</i> Slide the ON/OFF switch to the "ON" position. <i>Power off</i> Slide the ON/OFF switch to the "OFF" position.			Reorient or relocate the receiving antenna.     Increase the separation between the equipment and receiver.     Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.     Consult the dealer or an experienced radio/TV technician for help.
	Pair Wireless speaker with your mobile device	FAQ		RF warning statement:
	Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.     Power on the wireless speaker.     Activate the Biuetooth function on your phone within range and select "BT SPECTRUM SPK" from the list shown.     4. You will hear a beep sound when pairing is successful.	<ul> <li>If the Wireless speaker cannot be paired with your device, please try the following:</li> <li>Ensure that your speaker is in pairing mode or reconnection mode.</li> <li>Ensure that Bluetooth search function of your mobile device is activated.</li> </ul>		The device has been evaluated to meet general RF exposure requirement.
	Reconnect Wireless speaker to your mobile device	<ul> <li>If the Wireless speaker cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.</li> </ul>		FC
	When powered on, the wireless speaker will automatically connect with the last successfully paired device.			FCC ID: 2ADM5-SP-0485 FCC ID: 2ADM5-SP-0485 Keep All Relevant Information for Future Reference Distributed by 1616 Holdings. Inc. 701 Market Street. Suite 200 Philadelphia, PA 19106