


Settings <u>let you configure the tablet</u>, set Wi-Fi, Bluetooth and other preferences.

Tap the 🙀 Settings icon to go to settings.

## Introduction




Featuring a fast and responsive Octa-core processor, this tablet is perfect for accomplishing everyday tasks,

streaming music and movies, taking photos, checking emails, and engaging with social media.

The tablet offers 64GB of internal storage, Bluetooth connectivity, Micro SD slot for up to 128GB of additional storage, on-the-go productivity services, and a utility app.


The following information will help you get the most out of your tablet.

- What You Should Know to Ensure Best Performance:
- Use the in-box charger and USB cable to charge your tablet.
- Charge the battery completely before first use.
- While updates download in the background, tablet performance can be affected until completed.
- Close unused applications. Open apps that run in the background will affect overall performance.
- Battery Consumption: Play times on a fully charged battery will vary depending on your display settings,
- apps that remain open, and internet use(ie: streaming video content).
- Suggest customer use tablet screen protector and tablet case to protect the tablet.
- As constant improvement, UI display may vary slightly.







## Connecting to the Internet












Remove Keyboard and Folio Case llow below instruction to remove the folio case and keyboard. Grasp the side of the folio case and remove Grasp the side of the folio case and folio one case corner, then to remove the second


## Google Play Updates

The first time you sign on to Google Play, updates will automatically start downloading on to the tablet. Installing a new application while multiple apps are downloading will reduce tablet speed and performance.

After all downloads and updates have been installed, the tablet will resume normal operating performance.

To view the progress of downloads working in the background,slide your finger down from the top edge of the screen.





# Important Safety Instructions

- We would like you to have a safe and enjoyable experience.
- ease read the following instructions and notices before using your tablet. • Warning: This product may contain a chemical known to the State of California to cause cancer, birth defects, or other reproductive harm.
- Avoid using the tablet in extremely hot, cold, dusty, damp or wet environments.
- The tablet is not moisture/water-resistant. Avoid using the tablet around sources of water.
- · Avoid dropping or forcibly placing the tablet onto a hard surface. This may damage the screen or internal ctronic components and void the warrant Do not use alcohol, thinner or benzene to clean the surface of the tablet. Use only cleaning products designed
- computer tablet devices. o not use the tablet while walking or driving.
- cessive use of earphones at high volume may lead to hearing impairment. Limit earphone usage, and adjust he volume to a moderate level when doing so.
- mages in this guide may vary slightly from the actual produc
- harge the tablet battery under any of the following circumstances:
- The battery level icon indicates low power, by showing a drained, red battery icon.
- The tablet powers-off automatically, and continues to do so even after restarting.

• Do not suddenly disconnect the tablet when formatting, uploading or downloading data. This can lead to program errors(e.g., system or screen "freezing".)


- atic discharge is normal and can occur in an electronic device Although not life threatening, it may corrupt es or damage memory and its content. Dismantling the tablet will void the manufacturer's warranty.
- The tablet functions, hardware, software, and warranty information may be improved or modified by the manufacturer or their respective owners, and is subject to change without notice.

# Important Safety Instructions

1. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.


- 2. WARNING: Only use attachments/accessories specified or provided by the manufacturer(such as the exclusive supply adapter, battery etc).
- 3. WARNING: The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
- 4. WARNING: To reduce the risk of fire or electric, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids.
- Such as vases, shall not be placed on apparatus. 5. WARNING: Please refer the information on exterior bottom enclosure for electrical and safety information
- before installing or operating the apparatus.

Use the devices where the ambient temperature is between 0 and 35° C(32to 95° F). Low-or high-temperature conditions might cause the device to change its behavior to regulate its temperature. Using Android device in very cold conditions outside of its operating range might temporarily shorten battery life and could cause the device to turn off. Battery life will return to normal when you bring the device back to higher ambient temperatures. Using the devices in very hot conditions can permanently shorten battery life.




# **Starting Your Tablet**

1. During the setup process, slide up to unlock screen.



2. Once you' ve arrived at the Home screen, you can begin using your tablet.

### **APP Launch At-a-Glance**



### Swipe Right for Entertainment Space

- 1. After you have connected to Wi-Fi, from the home screen, slide your finger to the right to start Entertainment Space.
- 2. Select your content services from multiple providers and apps

3. Enjoy millions of games, tv shows, movies, and books from your favorite free and paid services and apps.

- 1. In the bottom right, press and hold the Parent menu 🚯 > Device Settings.
- 2. Go to Accounts to remove the account from the device.

Remove Kids Space

More details about Kids Space on g.co/KidsSpace

# Set up Google Kids Space

- Follow the steps below to set up Google Kids Space.
- 1. When asked who is going to use the device, tap **A child**. (If you've previously set up the tablet, tap on the Google Kids Space icon 桊 )
- 2. Sign into your child's existing Google Account or follow the prompts to create a new Google Account for your child under 13 (or the applicable age in your country).
- 3. When prompted to set up Google Kids Space, tap **Set Up**.
- 4. Edit your child's settings and interests.

### FCC Statement

his equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no uarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to dio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

nect the equipment into an outlet on a circuit different from that to which the receiver is connected.

t the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device ay not cause harmful interference, and (2) this device must accept any interference received, including interference hat may cause undesired operation.

Specific Absorption Rate (SAR) information:

This Tablet meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC BE Exposure Information and Statement the SAB limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: Tablet has also been tested against this SAR limit. This devicewas tested for typical body-worn operations with the back of the phone kept 0mm from the body. To maintain compliance with FCC RF exposure

requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and

# Walmart stores, Inc Limited Warranty

Walmart warrants this product against defects in material or workmanship for a period of one(1) year from the original date of purchase. During this period, Walmart will replace a defective part with a new or refurbished part without a charge to you. If your unit is deemed unrepairable, onn. will replace the unit with a new or refurbished unit at Walmart's sole discretion. The customer is responsible for transportation cost and insurance charges(if applicable) to Corporate. It is the customer's responsibility to retain original packaging or provide like packaging in order to facilitate the warranty process. Walmart will incur no liability whatsoever to provide packaging for warranty items. Should the product be damaged due to insufficient packaging, the warranty may be voided. You must receive a return authorization number (RMA #) before sending the unit in for service. Service that is provided is warranted for the duration of the original warranty or 45 days whichever is greater.

### Your Responsibility


It is strongly recommended to make a backup copy of the contents on your hard drive in case of operational failure. Walmart will not be held liable for content that is on the device. Retain a copy of the bill of sale to provide proof of purchase. The warranty extends only to defects in materials or workmanship as limited above and does not extend to a cracked screen, damaged USB or DC port, cosmetic damage, or any other products, parts or accessories that have been lost, discarded, damaged by misuse or accident, neglect, acts of God such as lightning, voltage surges in the home, improper installation, or serial number rendered illegible.

### Walmart stores, Inc Limited Warranty

Need help? We're here for you every day from 7 a.m. – 9 p.m. CST. Give us a call at 1-888-516-2630

You will be instructed on how your claim will be processed so have information available including date of purch ase, serial number and the problem with the product. Should a problem be determined to be within the limits of the warranty you will be provided with an(RMA) authorization number and instruction. Proof of purchase must be confirmed before any warranty service can be provided. Should a claim not be covered by the limited warranty, you will be asked whether you wish to have service provided for a fee.

Google, Android, Google Play and other marks are trademarks of Google LLC.



# 此页只是文件说明,不做印刷用!

文件名 File Name	21MHZ086-IM-V1.1		版次 _    Rivision _	V1.1	
机型 Project#	MID1105		比例 Scale	1:1	
客户/品牌 Customer			公差 Tolerance	$\pm$ 3mm	
尺寸+P数 Size	145*102mm, 28P		设计 Designer	邹剑文	
材 质 Material	80g双胶纸		审核 Checked _	卢银娟	
工艺 technique	单色印		设计日期 Design Date	2021.06.07	
注释: Remarks:		描述 Description			


## Tablet Updates

To ensure the tablet runs smoothly it is recommended to perform periodic system software updates, especially during initial set up of the tablet. You may receive notifications(on the Lock screen) from time to time that software updates are available.

Tap the notification to be directed to the update.

Other options to access updates: 1. Tab on Settings 🙀 > System > System Update.

NOTE: To perform an update, you must be connected to Wi-Fi.



### ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economi Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: device may not cause interference

(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES - 3 (B)/NMB - 3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licen

d'Innovation, Sciences et Développement économique Canada \_'exploitation est soumise aux deux conditions suivantes

Cet appareil ne doit pas provoguer d'interférences

2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance. cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes

sur l'exposition aux champs rf et la conformité

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. et équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement nor

pecific Absorption Rate (SAR) information:

This Tablet meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. ISEI RF Exposure Information and Statement the SAR limit of Canada(ISED) is 1.6 W/kg averaged over one gram of tissue. Device types: Tablet has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the Tablet kept 0mm from the body. To maintain compliance with ISED RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of the Tablet . The use of be clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with ISED RF exposure requirements, and should be avoided. nformations sur le débit d'absorption spécifique (DAS):

Cette tablette répond aux exigences du gouvernement en matière d'exposition aux ondes radio. Les lignes directrices so basées sur des normes élaborées par des organisations scientifiques indépendantes à travers une évaluation périodique et approfondie des études scientifiques. Les normes comprennent une marge de sécurité substantielle conçue pour assurer la sécurité de toutes les personnes, quel que soit leur âge ou leur état de santé. Information et déclaration d'ISDE sur l'expositic aux RF la limite DAS du Canada (ISDE) est de 1,6 W / kg en moyenne sur un gramme de tissu. Types d'appareils: la tablette également été testée par rapport à cette limite SAR. Cet appareil a été testé pour des opérations typiques portées sur le cou avec le dos de la tablette gardé à 0 mm du corps. Pour maintenir la conformité avec les exigences d'exposition RF d'ISDE. utilisez des accessoires qui maintiennent une distance de séparation de 0 mm entre le corps de l'utilisateur et l'arrière de la ablette. L'utilisation de clips de ceinture, d'étuis et d'accessoires similaires ne doit pas contenir de composants métalliqu dans son assemblage. L'utilisation d'accessoires qui ne satisfont pas à ces exigences peut ne pas être conforme aux exigences d'exposition aux RF d'ISDE et doit être évitée.

The device for operation in the band 5150–5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

appareil destiné à fonctionner dans la bande 5150-5250 MHz est uniquement destiné à une utilisation en intérieur afin de réduire le potentiel d'interférences nuisibles aux systèmes mobiles par satellite cocanaux.