

Accessories Options

SKU	Description
T2-MSR100	Magnetic Stripe Reader, 3-tracks
T2-MSC100	Combo Magnetic Stripe and Smart Card Reader
T2-BAR201	1D/2D Barcode Imager
T2-DOK201	Charging Dock for DASH7E1, includes Ethernet and 3 USB ports.
T2-LTE101	3G/LTE module, USA
T2-LTE601	3G/LTE module, Europe
T2-ACC101	Easy kit (Handstrap, Stylus)

Important Product and Safety information

1. Do not disassemble the device. It may damage the device, and void the warranty.
2. Operate the device in a place where temperature is between -10°C and +50°C.
3. Protect your device from water and moisture intake. Keep connector covers closed when not in use to prevent water and moisture intake.
4. Use only soft and dry lint-free cloth to clean the device.
5. Use only the power charger delivered with the device.
6. Do not use damaged power cords or plugs.
7. Save energy by doing following.
 - Reduce screen brightness and sound volume.
 - Close any applications and data connections that are not being used.
 - Disable sounds like touch sound.
 - Disconnect any peripherals from the device if they are not used.
 - Unplug the charger from the electrical outlet when it is not used.
8. The device contains replaceable battery. There is risk of explosion if battery is replaced by an incorrect type.
9.  Listening to the device at high volume levels for long periods may cause hearing damage.

This device complies with PART 15 of the FCC Rules. Operation is subject to following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



WEEE STATEMENT

The WEEE directive places an obligation on manufacturer who sell into EU countries to take back electronic products at the end of their useful life. The symbol (shown here) will be on PIONEERPOS products and/or packaging, which indicates that this product must NOT be disposed of with other waste. Instead it is the user's responsibility to dispose of their waste electrical and electronic equipment by handing it over to an approved reprocessor, or by returning it to PIONEERPOS for reprocessing. For more information about where you can send your waste equipment for recycling, please contact your local recycling facility or PIONEERPOS at dash@pioneerpos.com



Please visit us at www.pioneerpos.com
Send inquiry to dash@pioneerpos.com


DASH7E1 Tablet Quick Start Guide




Features





Packing Contents



Using the DASH for the first time

- 1 Charge the DASH with the power supply provided, and make sure the battery is fully charged before using the DASH. (3-4 hours charging time)
- 2 Check the Battery Status.*
 

*blinking amber LEDs indicate the device is charging. LEDs will turn off once the device is fully charged.
- 3 To turn on the DASH, press and hold the Power button for 3 seconds (Not the Home button)
 

- 4 When the DASH is on, the fully charged battery will be shown by the green LEDs.
 
- 5 To complete setting up the DASH, please follow the instructions in the operating system.