



Table of contents

1	Basics	3	5	Entering Text	18
	Activating Your Phone	3		Keypad Input	18
	Powering On or Off	4		Text Input Mode	19
	Charging Your Device	4		Changing Text Mode	20
	Phone Overview	5	6	Messages	21
	Setting Up Voicemail	7		Types of Messages	21
2	Getting Started	8		Creating and Sending New Text Messages	22
	Status Bar Icons	8		Creating and Sending New Multimedia Messages	22
	Menu Navigation	9		Reading New Messages	22
3	Phone Calls	11		Using Message Options	23
	Making a Call	11		Deleting Messages	24
	Answering a Call	12		Message Settings	24
	Ending a Call	13	7	Web	25
	Adjusting Call Volume	13		Launching Web	25
	Recent Calls	13		Accessing a WAP Site	26
	In-Call Options	14		Navigating with the Web	26
4	Contacts	15		Settings	27
	Using the contact list	15	8	Applications	27
	Adding New Contacts	16		Camera	27
	Editing/Deleting Contacts	16		Music Player	29
	Making a Call from Your Contact List	16		My Images	30
	Speed Dial List	17			
	Contacts Management	17			

	Video Player	30
	FM Radio.....	30
	Tone Recorder	31
9	Tools	32
	Alarm	32
	Calculator.....	33
	Calendar.....	33
	Notes	34
	Bluetooth®	34
10	My Folder	36
	Buy Ringtones and Graphics.....	36
	Phone.....	36
	Memory Status.....	36
11	Settings	36
	Accessing the Settings Menu.....	36
	Sound	36
	Phone Settings.....	37
	Call Settings.....	39
	Airplane mode	40
	Security.....	40
	Restore default.....	41
12	Safety and Use	41
13	General Information.....	50



www.sar-tick.com

This product meets applicable national SAR limits of 1.6W/kg. The specific maximum SAR values can be found in the RADIO WAVES section of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 1 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

