200.0 mm



Pairing Your Headphones with a Bluetooth



blue to indicate that your headphones are in pairing mode

The LED indicator lights will turn blue to indicate that your headphones are paired with your phone. Note that the light will blink slowly anytime music is playing.

Press and hold the power button to power on your headphones.



Make sure that Bluetooth is turned or Connect to the device listed as "SS68-BT-TA"

Using Your Headphones

Powering Your Headphones On and OFF

1. Press and hold the power button in order to power on your headphones. If you have paired your headphones to your Bluetooth device previously, they will automatically remain paired each time you power

on your headphones.

2. Press and hold the power button in order to power off your headphones.

Listening to Music

Pause Button : Press to play or pause a track.

NOTE: You can adjust volume and playback settings on your phone or connected audio device.

Answering a Call: Quickly press the Answer button to answer an incoming call
 Ending a Call: Quickly press the Answer Call button to end a call.


Auxiliary Input Mode

To use your headphones with devices that are not Bluetooth enabled, plug one end of a standard 3.5mm audio cable into the Auxiliary Port on your headphones. Plug the other end into the

A Quick Look at Your Device



Charging Your Headphones





Insert the USB charging cable's standard USB plug into the USB ports of a computer or suitable USB charging adapter.

The LED indicator light turns red while the headphones are charging. It turns blue once charging is complete.

Charging takes 1-2 hours. Unplug when

Important: To avoid a complete discharge of the battery, charge your headphones at least once every six

Important Safety Precautions

es, basic safety precautions should always be followed, including the following:

- READ ALL INSTRUCTIONS BEFORE USING YOUR HEADPHONES.

- 1. READ ALL INSTRUCTIONS EFFORE USING YOUR HEADPHONES.
 2. Do not use your headphones on any wet surfaces.
 3. Do not place your headphones on any wet surfaces.
 4. Do not allow of wheelphones on any wet surfaces.
 5. Do not allow of which or the infilm to lay with your headphones without adult supervision.
 5. Do not allow of the surface of the surface



mm

BATTERY WARNING:

IATTERY WARNING:
The device is equipped with an integrated lithium ion battery. The battery cannot be replaced. Do not attempt to remove the battery from the device Do not dispose of in fire or expose to excessive heat.

Do not crush, puncture, incinerate, or short circuit external contacts. Please recycle or dispose of the battery properly. Contact your local ecycling facilities and/or the manufacturer for further information.

Introduction

Thank you for purchasing your Vivilar Bluetooth Headphones, item \$588-BT-TA. You can use your headphones with most smartphones and Bluetooth devices to stream music and enjoy hands-free calling. In order to get the best results when using this device, please read this manual first before using.

Package Contents

-Vivitar SS68-BT-TA Bluetooth Headphones -Micro USB Charging Cable -User's Manual with Warranty Information

Specifications

Frequency Range: 2402MHz-2480MHz Bluetoth Range: Up to 33 Feet (10 Meters)
Charging Input: DC 5V
Battery Type: Lithium Polymer Battery Charge Time: Approximately 2 Hours

Maintenance and Care

-Before using your headphones, inspect the ports to make sure that they are clear of dust and debris before

-Use a soft cloth to clean your headphones. Never use any harsh chemicals or detergents. Make sure your

-When your headphones are not in use, they should be stored in a cool, dry place.

-Never tug or yank on the charging cable while it is connected to your headphones. Connect and disconnect this cable as carefully as possible

-Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture or

-Please recycle or dispose of your headphones properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of your headphones for further information.



One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information

Call 1-800-592-9541 in the U.S. or visit our website at www.vivitar.com

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received. including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- -- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

One Year Warranty (continued)

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY, DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE BINDING ON DISTRIBUTOR'S SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO AMAGES FOR LOSS OF PROFITS, BUSINESS, SAMINSS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRAN-TIES SHALL APPLY NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized relater to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.