


## TEST THE SOUND LEVEL AND POSITION THE VIDEO MONITOR

### Testing the sound level of the video monitor

**NOTE**  
This baby monitor is intended as an aid. It is not a substitute for proper adult supervision, and should not be used as such.

**CAUTION**  
For hearing protection, make sure the parent unit is more than 10 feet (3m) away from the baby unit. If you hear any feedback noise from the parent unit, move the parent unit further until the noise stops. You can also press VOL - on the parent unit to lower or mute the noise.

**TIP**  
Increase the parent unit speaker volume if you cannot hear the sounds transmitted from the baby unit.




### Positioning the video monitor

**CAUTION**  
Keep the baby unit out of the reach of your baby. Never place or mount the baby unit inside the baby's cot or playpen.

Excessive downward camera tilt may impair night vision and sound reception. If so, please adjust the tilt slightly upward.

1. Place the baby unit more than 3 feet (1m) away from your baby.



2. Adjust the angle of the baby unit to aim at your baby.




## MOUNT THE BABY UNIT (OPTIONAL)


### NOTES

Check the reception strength and baby unit camera angle before drilling any holes:  
The types of screws and anchors you need depend on the composition of the wall. You may need to purchase the screws and anchors separately to mount your baby units.


3. Align the wall mount bracket and screws with the holes in the wall as shown. Tighten the screw in the middle hole first, so that the wall mount bracket position is fixed. You can tighten the other screw in the top hole.




4. Place the baby unit on the wall mount bracket, and then slide it forward until it locks into place. Connect the power adapter to the baby unit and a power supply.



5. You can maximise your baby unit's viewing angles by tilting the wall mount bracket. Hold the baby unit, and then rotate the knob in an anticlockwise direction. This will loosen the joint of the wall mount bracket. Tilt your baby unit up or down to adjust to your preferred angle. Then, rotate the knob in a clockwise direction to tighten the joint and secure the angle.



- To avoid causing feedback noise from your video monitor:
  - Make sure your baby unit and parent unit are more than 10 feet (3m) apart; OR
  - Turn down the volume of your parent unit.



## NEED HELP?

For instructions and guides to make the best use of your baby monitor, and for the latest information and support, check out our online help topics and FAQs. The online help page will also be updated periodically to reflect product system updates.

Use your smartphone or mobile device to access our online help.

- Go to <https://help.vtechphones.com/rm7764hd> or <https://help.vtechphones.com/rm7764-2hd>; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help.
- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

If you would like to contact us, visit <https://help.vtechphones.com/cs>.

You can also call our Customer Support at 1-844-848-8324 (1-844-84-VTECH) [in US] or 1-888-211-2005 [in Canada] for help.

RM7764HD online help



RM7764-2HD online help



## BASIC OPERATION

After powering up your video monitor, the parent unit streams live video in Direct mode. We recommend you follow the instructions on screen to set up a home Wi-Fi network connection with your monitor for mobile/tablet remote access and receiving firmware updates. See [Download app for mobile access](#) in this quick start guide.

### Use the menu

Press MENU on the parent unit to enter the main menu, choose a menu item, or save a setting. You can use the parent unit menu for advanced settings or operations, such as to play or stop the baby unit lullaby, or adjust the baby unit sound sensitivity.

While in the menu:

- Press **A**, **V**, **<** or **>** to scroll among the menu options.
- Press **MENU/SELECT** to select an item.
- Press **TALK/** to return to the previous menu or live video.

### Adjust speaker volume

Press VOL - / VOL + to adjust the parent unit speaker volume level received from the baby unit.

Use your smartphone or mobile device to access our online help.

- Go to <https://help.vtechphones.com/rm7764hd> or <https://help.vtechphones.com/rm7764-2hd>; OR
- Scan the QR code on the right. Launch the camera app or QR code scanner app on your smartphone or tablet. Hold the device's camera up to the QR code and frame it. Tap the notification to trigger the redirection of the online help.
- If the QR code is not clearly displayed, adjust your camera's focus by moving your device closer or further away until it is clear.

If you would like to contact us, visit <https://help.vtechphones.com/cs>.

You can also call our Customer Support at 1-844-848-8324 (1-844-84-VTECH) [in US] or 1-888-211-2005 [in Canada] for help.

RM7764HD online help



RM7764-2HD online help



### Zoom

Press **Q** to scroll through **Q**, **Q**, **Q**, **Q** in a fixed zoom sequence, allowing you to zoom in or out. The displayed zoom icon indicates the level of magnification for the image.

