

Date: 17 OCT 2024  
Product: SP-0162 IM

SKU:




SP-0161 SOUND TOP WIRELESS SPEAKER IM  
Size: 322.5(w) x 100(h) mm

# SOUND TOP WIRELESS SPEAKER

## Instruction Manual

Thank you for purchasing the Sound Top Wireless Table Speaker. This manual provides more information about this wireless speaker, please read the instructions before using.



8w

SUPERIOR SOUND

FOR INDOOR USE ONLY

Product Overview

Front

Back

1

2

3

4

5

6

POWER

MODE

DC 5V

DOWN

UP

LED Indicator

Power On/Off Button

Mode Button (Speaker/FM Radio)

USB Type-C Charging Port

Volume Down/Previous Sound Button

Volume Up/Next Sound Button

Package Contents

Sound Top Wireless Speaker x 1  
Leg x 4  
EVA Sticker x 8

USB Type-C Charging Cable x 1  
Instruction Manual x 1

Technical specification

Driver Diameter: 100 mm  
Impedance: 3 Ohms  
Power Supply: DC 5V/1A  
Battery: Li-Ion Battery 3.7V 2600 mAh  
Playtime: 4.5-5 Hours  
Charging Time: 4-5 Hours  
Bluetooth Range: 32.8 Feet  
Bluetooth Version: 5.3

50cm USB Type-C Charging Cable (Included)  
With FM Radio Function  
USB Type-C Charging Cable rating 5V/1A Max.  

MAXIMUM WEIGHT LIMIT

30 LBS.  
13.6 KG

How To Assemble

A

Screw the leg into the hole at the bottom panel of the speaker.

B

Repeat the assembly sequence for the remaining legs.

C

Check all legs are well fixed.

D

Place a EVA sticker (Attached) on the bottom side of leg if uneven happened.

CAUTION: DO NOT OVER TIGHTEN!

Power On/Off

Power on

Press and hold the Power Button for 2 seconds.

Power off

Press and hold the Power Button for 2 seconds.

Note: Always power off the speaker when not in use.

Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.

2. Power on the wireless speaker.

3. Activate the Bluetooth function on your phone within range and select "SP-0162 SPK" from the list shown.

4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Change the Mode for the Wireless Speaker

Press the "MODE" Button one time to change to FM Radio mode and press the "MODE" Button one time to change back to Bluetooth mode.

FM Radio

Auto Scan all Channels

Press Power Button once.

Next Channel

Press Up Button once.

Previous Channel

Press Down Button once.

Volume Up

Press and hold Up Button.

Volume Down

Press and hold Down Button.

Charging your Wireless speaker

⚠ For your safety, please always use appropriate 5V input charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the USB Type-C charging cable provided with this wireless speaker.

2. Connect the USB Type-C plug to USB Type-C charging port on the speaker, then connect the USB plug to a USB port on a wall adapter to begin charging.

3. The LED Indicator will turn orange while charging and will turn off once fully charged.

Note:

- You must select a qualified charger from a regular manufacturer.

- You must charge the Wireless speaker if it has been not used for more than 6 months.

USB Plug

USB Type-C Charging Plug

CAUTION:

The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

USB Type-C Charging Cable rating 5V/1A Max.

FAQ

♦ If the Wireless speaker cannot be paired with your device, please try the following:

Ensure that your speaker is in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.

♦ If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

⚠ Safety instructions for the lithium battery and charging the product

-The input voltage to the product is DC 5V 1A.

-In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/adapter for charging the product.

-Only charge the product at ambient temperatures between 10°C/50°F and 40°C/104 °F.

- Do not heat above 70°C/158°F, eg. Do not expose to sunlight or throw into fire.

-Switch off the product after use.

-Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

• Increase the separation between the equipment and receiver.

• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

• Consult the dealer or experienced radio/ TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.

FCC ID: 2ADM5-SP-0162

ITEM# SP-0162-BLACK

Distributed by 1616 Holdings, Inc.

701 Market Street, Suite 200

Philadelphia, PA 19106

Made in China

Keep All Relevant Information For Future Reference

Approval:

Date: